

Proton V10.08 Diagnostics List(Note:For reference only)

Menu			Functions					
Model	System	System	Sys. Info.	Read Code	Clear Code	Data Stream	Action Test	Special Functions
Preve	ECU		√	√	√	√	√	√
Preve	TCU		√	√	√	√		√
Preve	ABS	ABS9	√	√	√	√	√	√
Preve	ABS	ESP9	√	√	√	√	√	√
Preve	BCM		√	√	√	√	√	√
Preve	SRS		√	√	√	√		√
Preve	Gear Shift Lock		√	√	√			
Suprima S	ECU		√	√	√	√	√	√
Suprima S	TCU		√	√	√	√		√
Suprima	ABS	ABS	√	√	√	√	√	√
Suprima S	ABS	ESP9	√	√	√	√	√	√
Suprima S	BCM		√	√	√	√	√	√
Suprima S	SRS		√	√	√	√		√
Suprima S	Gear Shift Lock		√	√	√			
Suprima S	Meter		√	√	√	√		√
SATRIA	ECU	EMS400	√	√	√	√	√	√
SATRIA	ECU	MMC_ECM		√	√	√	√	√
SATRIA	TCU	TRANSMISSION(ISO)		√	√	√	√	
SATRIA	TCU	TRANSMISSION(MUT)		√	√	√	√	
SATRIA	ABS	TEVES_MK20		√	√	√	√	√
SATRIA	IMMO	MMC_IMM		√	√	√	√	√
SATRIA	IMMO	SIEMENS	√	√	√	√		
WIRA	ECU	EMS400	√	√	√	√	√	√
WIRA	ECU	MMC_ECM		√	√	√	√	√
WIRA	TCU	TRANSMISSION(ISO)		√	√	√	√	

Proton V10.08 Diagnostics List (Note: For reference only)

Menu			Functions					
Model	System	System	Sys. Info.	Read Code	Clear Code	Data Stream	Action Test	Special Functions
WIRA	TCU	TRANSMISSION(MUT)		√	√	√	√	
WIRA	IMMO	MMC_IMM		√	√	√	√	√
WIRA	IMMO	SIEMENS	√	√	√	√		
PERDANA	ECU	MMC_ECM		√	√	√	√	√
PERDANA	TCU	TRANSMISSION(MUT)		√	√	√	√	
PERDANA	ABS	MMC_ABS		√	√	√	√	
PERDANA	ABS	TEVES_MK20		√	√	√	√	√
JUARA	ECU	MMC_ECM		√	√	√	√	√
JUARA	TCU	TRANSMISSION(ISO)		√	√	√	√	
JUAR	EP	MMC_EP		√	√	√	√	
EXORA	ECU	EMS700	√	√	√	√	√	√
EXORA	TCU	TRANSMISSION(ISO)		√	√	√	√	
EXORA	ABS	TRW_EBC450		√	√	√	√	√
EXORA	SRS	SRE_SMART_11_Auto Liv		√	√	√		
EXORA	BCM	BCF_Continental		√	√	√	√	√
EXORA Bold	ECU			√	√	√	√	√
EXORA Bold	TCU		√	√	√	√		√
EXORA Bold	ABS		√	√	√	√	√	√
EXORA Bold	SRS		√	√	√	√	√	
EXORA Bold	BCM			√	√	√		√
SAGA BLM	ECU	EMS700	√	√	√	√	√	√
SAGA BLM	TCU	TRANSMISSION(ISO)		√	√	√	√	
SAGA BLM	SRS	AC3	√	√	√	√		√
SAGA BLM	IMMO	SIEMENS	√	√	√	√		

Proton V10.08Diagnostics List(Note:For reference only)

Menu			Functions					
Model	System	System	Sys. Info.	Read Code	Clear Code	Data Stream	Action Test	Special Functions
SAGA FL	ECU	EMS700	√	√	√	√	√	√
SAGA FL	TCU	TRANSMISSION(ISO)		√	√	√	√	
SAGA FL	SRS	ACU3	√	√	√	√		
SAGA FL	SRS	AC3	√	√	√	√		√
SAGA FL	IMMO	SIEMENS	√	√	√	√		
SAGA FLX	ECU			√	√	√	√	√
SAGA FLX	TCU		√	√	√	√		√
SAGA FLX	ABS	ABS9	√	√	√	√	√	√
SAGA FLX	ABS	ESP9	√	√	√	√	√	√
SAGA FI	SR	ACU:	√	√	√	√		
SAGA FLX	SRS	AC3	√	√	√	√		√
PERSONA	ECU	EMS700	√	√	√	√	√	√
PERSONA	TCU	TRANSMISSION(ISO)		√	√	√	√	
PERSONA	ABS	BOSCH_ABS	√	√	√	√		√
PERSONA	SRS	AC3	√	√	√	√		√
PERSONA	IMMO	SIEMENS	√	√	√	√		
SatriaNeo	ECU	EMS700	√	√	√	√	√	√
SatriaNeo	TCU	TRANSMISSION(ISO)	√	√	√	√	√	
SatriaNeo	ABS	BOSCH_ABS	√	√	√	√		√
SatriaNeo	SRS	AC3	√	√	√	√		√
SatriaNeo	IMMO	SIEMENS	√	√	√	√		
SAVVY	ECU	RENAULT12	√	√	√	√	√	√
SAVVY	TCU	RENAULT12_TCU	√	√	√	√	√	√
SAVVY	ABS	TEVES_MK60		√	√	√	√	√
SAVVY	SRS	AC3	√	√	√	√		√

Proton V10.08 Diagnostics List(Note:For reference only)

Menu			Functions					
Model	System	System	Sys. Info.	Read Code	Clear Code	Data Stream	Action Test	Special Functions
SAVVY	SRS	AC6	√	√	√	√		
Chancellor	ECU	MMC_ECM		√	√	√	√	√
Chancellor	TCU	TRANSMISSION(MUT)		√	√	√	√	
Chancellor	ABS	TEVES_MK20		√	√	√	√	√
GEN2	ECU	EMS700	√	√	√	√	√	√
GEN2	TCU	TRANSMISSION(ISO)		√	√	√	√	
GEN2	ABS	BOSCH_ABS	√	√	√	√		√
GEN2	ABS	TRW_ABS	√	√	√	√	√	√
GEN2	SRS	AC3	√	√	√	√		√
GEN2	IMMO	SIEMEN	√	√	√	√		
WAJA	ECU	EMS700	√	√	√	√	√	√
WAJA	ECU	RENAULT18	√	√	√	√	√	√
WAJA	ECU	MMC_ECM		√	√	√	√	√
WAJA	TCU	RENAULT18_TCU	√	√	√	√	√	√
WAJA	TCU	TRANSMISSION(ISO)		√	√	√	√	
WAJA	TCU	TRANSMISSION(MUT)		√	√	√	√	
WAJA	ABS	TRW_ABS	√	√	√	√	√	√
WAJA	ABS	BOSCH_ABS	√	√	√	√		√
WAJA	ABS	TEVES_MK20		√	√	√	√	√
WAJA	ABS	TEVES_MK60		√	√	√	√	√
WAJA	SRS	AC6	√	√	√	√		
WAJA	IMMO	MMC_IMM		√	√	√	√	√
WAJA	IMMO	SIEMENS	√	√	√	√		
ARENA	ECU	EMS400	√	√	√	√	√	√
ARENA	TCU	TRANSMISSION(ISO)		√	√	√	√	

Proton V10.08 Diagnostics List (Note: For reference only)

Menu			Functions					
Model	System	System	Sys. Info.	Read Code	Clear Code	Data Stream	Action Test	Special Functions
ARENA	TCU	TRANSMISSION(MUT)		√	√	√	√	
ARENA	IMMO	SIEMENS	√	√	√	√		
PUTRA	ECU	MMC_ECM		√	√	√	√	√
PUTRA	TCU	TRANSMISSION(MUT)		√	√	√	√	
PUTRA	ABS	TEVES_MK20		√	√	√	√	√
PUTRA	SRS	AC6	√	√	√	√		
INSPIRA	ENGINE		√	√	√	√	√	√
INSPIRA	AT		√	√	√	√		
INSPIRA	Auto Cruise		√	√	√	√		
INSPIRA	ABS		√	√	√	√	√	√
INSPIRA	SRS Airbag		√	√	√	√	√	
INSPIRA	Immobiliser		√	√	√	√	√	√
INSPIRA	AC		√	√	√	√	√	
INSPIRA	METER		√	√	√	√	√	√
INSPIRA	EATCS		√	√	√	√		√
INSPIRA	LIN		√	√	√	√		√