

## PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions	
106REMO DELAGE	1996-2004	Petrol engine	CDY BOSCH MA3.1	V,C	
			CDZ BOSCH MA3.1	V,C	
			HDY BOSCH MA3.1	V,C	
			HDZ BOSCH MA3.1	V,C	
			HFX BOSCH M7.4.4	V,C,D,T,S1,S2	
			KFX BOSCH MP7.3	V,C,D,T,S2	
			KFX MM1AP	V,C,D	
			KFW SAGEM S2000	V,C,D,T,S3,S2	
			NFX MM1AP	V,C,D,T,S2	
			NFZ BOSCH MP5.2	V,C,D	
		NFX MM48P	V,C,D		
Additional heating			V,C,D,T		
107	2005->	Petrol engine	CFA BOSCH ME7.9.5	C,D,T	
		Diesel engine	8HT SIEMENS SID805	V,C,D,T,S1,S3	
		AT	controlled manual	C,D	
		ABS	ABS BOSCH 8.0 C1	C,D	
			ESP BOSCH 8.0 C1	C,D	
		Subsystems	Airbag ECU	V,C,D	
			Coded anti-star	C,D	
			Power steering	V,C,D	
Radio	V,C,D,T,S1				
1007 CAN	2006-2009	Built-in systems interface(BSI)		V,C,B1	
		Petrol engine	KFU MM6LPC	V,C,D,T,S1,S2	
			KFV J34P	V,C,D,T,S1,S2	
			NFU BOSCH ME7.4.5	V,C,D,T,S1,S2	
		Diesel engine	8HX SID 806 DV4	V,C,D,T,S1	
			8HZ SID 806 DV4	V,C,D,T,S1	
			9HT BOSCH EDC16C3	V,C,D,T,S1,S5,S6,S7	
			9HZ BOSCH EDC16C3	V,C,D,T,S1,S5,S6,S7	
		A/T	controlled manual	V,C,D,T,S7,S12,S28	
				Multiplexed additive	V,C,D
		ABS	ABS MK70.1	V,C,D,T,S1,S17	
			ESP MK60-O	V,C,D,T,S1,S17,S16	
		Airbag ECU	Airbag ECU	V,C,D,S1,S14	
		Vehicle	Alarm	V,C,D,T,S1	
				Rain/brightness sensor	V,C
		Driving assistance/Comfort	Parking assistance		V,C,D,T,S1
			Air conditioning		V,C,D,T,S1
Under inflation			V,C,D		
Power steering			V,C,D,S1		

## PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
		Inform the driver/Audio/Communication	Multi-function display	
			Steering wheel	V,C,D,T
			Radio	V,C,D,T,S1
			Hands Free Kit	V,C,D,T,S1
			CD player	V,C,T
			Instrument panel	V,C,D,T,S1
			Telematics	V,C,D,T,S1
		Sliding side doors	V,C,D,T	
1007 VAN	2005-2006	Built-in systems interface(BSI)		V,C,B1
		Petrol engine	NFU ME744	V,C,D,T,S1,S2
			KFV J34P	V,C,D,T,S1,S2
			KFV S2000PM2	V,C,D,T,S1,S2
			KFU MM6LP	V,C,D
			N6A BOSCH ME7.4.5	V,C,D,T,S1,S2,S3
			N6B BOSCH ME7.4.5	V,C,D,T,S1,S2,S3
		Diesel engine	NFU BOSCH ME7.4.5	V,C,D,T,S1,S2,S3
			8HZ SIEMENS SID 804	V,C,D,T,S1
		ABS	8HX SIEMENS SID804	V,C,D,T,S1
			ABS MK70	V,C,D,T,S1,S17
		A/T	ESP MK60	V,C,D,T,S1,S17,S16
			Controlled manual	V,C,D,T,S1,S12,S7,S13
		Air bag	Airbag ECU	V,C,D,S1
		Visibility/Lighting/Signalling	Rain/brightness sensor	V,C
			Steering wheel	V,C,D,T
		Driving assistance/Comfort	Parking assistance	V,C,D,T
			Air conditioning	V,C,D,T,S1
			Power steering	V,C,D
		Inform the driver/Audio/Communication	Telematics RT3	V,C,D,T,S1
			Multi-function display	V,C,D
CD player	V,C,D,T,S1			
Instrument panel	V,C,D,T,S1			
Radio	V,C,D,T,S1			
		BSI		V,C,D,T,S2,B2
			NFU BOSCH ME744	V,C,D,T,S1,S2
			RFR MM48P	V,C,D,T,S2
			N6A BOSCH ME745	V,C,D,T,S1,S2,S3
			NFU BOSCH ME745	V,C,D,T,S1,S2,S3
			N6A BOSCH ME744	V,C,D,T,S1,S2
			N6A BOSCH ME744	V,C,D,T,S1,S2
			NFU Or N6A Or N6B	V,C,D,T,S1,S2
			KFW ME749	V,C,D,T,S1,S2,S9

KFW ME749 BIOFLEX V,C,D,T,S1,S2,S9

**PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
206	1998-2001	Petrol engine	RFN MM48P	V,C,D,T,S1,S2
			KFX BOSCH MP7.3	V,C,D,T,S2
			KFX MM1AP	V,C,D
			KFU MM6LP	V,C,D,S2
			HFZ MM1AP	V,C,D,T,S2
			HFY MM1AP	V,C,D,T,S2
			KFW SAGEM S2000	V,C,D,T,S3,S2
			K6D SAGEM S2000	V,C,D,T,S3,S2
			K6C MM1AP	V,C,D,T,S2
			HFX MM4.8P	V,C,D,T,S1,S2
			RFK MM6LP	V,C,D,T,S1
			RFN MM6LP	V,C,D,S2
			7LZ MM5NP	V,C
			KFW BOSCH ME7.4.4	V,C,D,T,S1,S2
			NFZ BOSCH MP7.2	V,C,D,T
			KFW J34P	V,C,D,T,S1,S2
			K6D J34P	V,C,D,T,S1,S2
			NFU J35	V,C,D,T,S1
			Diesel engine	8HX/8HZ BOSCH
		8HZ BOSCH EDC16C3		V,C,D,S4
		9HY BOSCH EDC16C3 EURO4		V,C,D,T,S4
		9HY BOSCH EDC16C3		V,C,D,T,S1,S4
		9HZ BOSCH EDC16C3		V,C,D,T,S1,S4
		9HX EDC16C3		V,C,D,T,S1,S4
		9HT BOSCH EDC16C3		V,C,D,T,S1,S4
		WJY LUCAS DCN2		V,C,D,T,S1
		WJZ LUCAS DCN2		V,C,D
		RHY BOSCH EDC15C2		V,C,D,T,S1,S5
		ABS	ABS MK70	V,C,D,T,S1,S17
			Anti-lock brakes	V,C,D,T,S17
		A/T	AL4 automatic gearbox	V,C,D,T,S3,S2,S12,S30
			ZF 4HP20 AT	V,C,D
			Diesel fuel additive	V,C,D,T,S1
			Electric pump	V,C,D
		IP	Instrument panel	V,C,D,T,S3
		A/C	Air conditioning	V,C,D,T,S1
			Alarm	V,C,D,T,S1
		Visibility/Lighting	Driving school	V,D,T
			Rain/brightness sensor	V,C

			Display/Telematics	V,C,D,T,S3
<b>PEUGEOT V10.12 Diagnostics List(Note:For reference only)</b>				
Vehicle	Year	System	ECU Type	Functions
		Driver information	on-board navigation	V,C,D
			Instrument panel	V,C,D,T,S1
			Radio	V,C,D,T,S1
			CD Player	V,C,D,T
		Airbag ECU	Air bag and seat belt	V,C,S3
			Left side airbag	V,C,S3
			Right side airbag	V,C,S3
206 MUX	2001-2008	Built-in systems interface(BSI)		V,C,B1
		Petrol engine	HFX MM48P	V,C,D,T,S1,S2
			HFY MM1AP	V,C,D,T,S2
			HFZ MM1AP	V,C,D,T,S2
			K6C MM1AP	V,C,D,T,S2
			K6D SAGEM S2000	V,C,D
			KFU MM6LP	V,C,D
			KFW BOSCH ME7.4.4	V,C,D,T,S1,S2
			KFW J34P	V,C,D,T,S1
			KFW SAGEM S2000	V,C,D
			KFX BOSCH MP7.3	V,C,D,T,S2
			KFX MM1AP	V,C,D
			N6A BOSCH ME7.4.4	V,C,D,T,S1,S2
			N6A BOSCH	V,C,D,T,S1,S2
			N6A BOSCH ME7.4.5	V,C,D,T,S1,S2,S3
			NFU BOSCH ME7.4.4	V,C,D,T,S1,S2
			NFU BOSCH ME7.4.5	V,C,D,T,S1,S2,S3
			NFU Or N6A Or N6B	V,C,D,T,S1,S2
			KFW ME749	V,C,D,T,S1,S2,S9
			KFW ME749 BIOFLEX	V,C,D,T,S1,S2,S9
			NFU J35	V,C,D,T,S1
			K6D J34P	V,C,D,T,S1,S2
			NFZ BOSCH MP7.2	V,C,D,T
			RFK MM6LP	V,C,D,T,S1
			RFN MM6LP	V,C,D
			RFN MM48P	V,C,D,T,S1,S2
			RFR MM48P	V,C,D,T,S2
			8HX/8HZ BOSCH	V,C,D,T,S1,S4
		8HZ BOSCH EDC16C3	V,C,D,S4	
		9HY BOSCH EDC16C3 EURO4	V,C,D,S4	
		9HT BOSCH EDC16C3	V,C,D,T,S1,S4,S30	

		Diesel engine	9HY BOSCH EDC16C3	V,C,D,T,S1,S4,S30
			9HZ BOSCH EDC16C3	V,C,D,T,S1,S4,S30
<b>PEUGEOT V10.12 Diagnostics List(Note:For reference only)</b>				
Vehicle	Year	System	ECU Type	Functions
			9HX EDC16C3	V,C,D,T,S1,S4,S30
			RHY BOSCH EDC15C2	V,C,D,T,S1,S5
			WJY LUCAS DCN2	V,C,D,T,S1
			Diesel fuel additive	V,C,D,T,S1
		AT	AL4 automatic gearbox	V,C
		ABS	ABS MK70	V,C,D,T,S1,S17
			Anti-lock brakes MK70	V,C,D,T,S1,S17
			Anti-lock brakes TEVES	V,C,D
			ESP MK60	V,C,D,T,S1,S17,S16
		Air bags	Air bags	V,C,D,T,S1,S14
		A/C	Air conditioning	V,C,D,T,S1
			Alarm	V,C,D,T,S1
		Visibility/Lighting	Driving school	V,D,T
			Rain/brightness sensor	V,C
		Driver information/Communication	Display/Telematics/AM	V,C,D,T,S1
			Display/Telematics/RT3	V,C,D,T,S1
			Radio	V,C,D,T,S1
			CD player	V,C,D,T
			Instrument panel	V,C,D,T,S1
			Electric pump	V,C,D
206 +	2008->	Built-in systems interface(BSI)		V,C,B1,D,S7,S29
		Petrol engine	KFW J34P	V,C,D,T,S1,S2
			TU5JP4 ME745	V,C,D,T,S1,S2
			NFU Or N6A ME749	V,C,D,T,S1,S2,S9
			N6A ME749 BIO FLEX	V,C,D,T,S1,S2,S9
			KFW ME749	V,C,D,T,S1,S2,S9
			KFW ME749 BIO FLEX	V,C,D,T,S1,S2,S9
		Diesel engine	RHY EDC15C2	V,C,D,T,S1,S5
			8HZ BOSCH EDC16C3	V,C,D,S4
			9HY BOSCH EDC16C3	V,C,D,S4
		AT	AL4 automatic gearbox	V,C,D,T,S1,S2,S12
		Active safety	ABS MK70	V,C,D,T,S1,S17
			ESP MK60	V,C,D,T,S1,S17,S16,S2
			Air-bag	V,D,S1,S14
		A/C	Air conditioning	V,C,D,T,S1
			Alarm	V,C,D,T,S1
			Rain/brightness sensor	V,C
	Display/Telematics	V,C,D,T,S1		

Inform the driver/Audio/Communication	Steering wheel	V,C,D,T
	Radio	V,C,D,T,S1
	CD player	V,C,D,T,S1

## PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
			Instrument panel	V,C,D,T,S1
			Electric power steering	V,C,D,T
		Multi-function display	AMF	V,C,D,T,S1
			RT3	V,C,D,T,S1
			Services module	V,C,D,T,S1
		Built-in systems interface(BSI)		V,C,D,B1,S7,S29
		Petrol engine	N6A BOSCH ME7.4.5	V,C,D,T,S1,s2,s3
			N6B BOSCH ME7.4.5	V,C,D,T,S1,s2,s3
			NFU BOSCH ME7.4.5	V,C,D,T,S1,s2,s3
			KFU MM6LPC	V,C,D,T,S1,S2
			5FW MEV17.4	V,C,D,T,S1,S2
			5FX MED17.4	V,C,D,T,S1,S2
			5FY MED17.4	V,C,D,T,S1,S2
			5FR MED17.4	V,C,D,T,S1,S2
			8FS MEV17.4	V,C,D,T,S1,S2
			5FS MEV17.4	V,C,D,T,S1,S2
			8FR MEV17.4	V,C,D,T,S1,S2
			8FP MEV17.4	V,C,D,T,S1,S2
			MEV17.4 EVO	V,C,D,T,S1
			KFV J34P	V,C,D,T,S1,S2
			KFT V34.1	V,C,D,T,S1,S2
			EP3C 8FP MEV17.4.2	V,C,D,T,S1,S2
			EP3CM 8FP MEV17.4.2	V,C,D,T,S1,S2
			EP3C 8FR MEV17.4.2	V,C,D,T,S1,S2
			EP6C 5FS MEV17.4.2	V,C,D,T,S1,S2
			Diesel engine	8HZ BOSCH EDC16C3
		9HX BOSCH EDC16C3		V,C,D,T,S4
		9HY BOSCH EDC16C3		V,C,D,T,S4
		9HY BOSCH EDC16C3		V,C,S4
		9HZ BOSCH EDC16C3		V,C,D,T,S1,S5,S6,S7
		9HV BOSCH EDC16C3		V,C,D,T,S1,S5,S6,S7
		9HY BOSCH EDC16C3		V,C,D,T,S4
		9HT BOSCH EDC16C3		V,C,D,T,S4
		EDC16C3DV4		V,C,D,T,S1,S21,S26
		9HP BOSCH EDC17C10		V,C,D,T,S1,S5,S6,S2
		8HR BOSCH EDC17C10		V,C,D,T,S1,S5,S6,S2
		9HL HDI SID807		V,C,D,T,S1,S5,S6,S2,S21
		9HR HDI SID807		V,C,D,T,S1,S5,S6,S2,S21

207CAN	2007->		HDI_SID807_BR2	V,C,D,T,S1,S2,S5
			9HP_EDC17C10_BR2	V,C,D,T,S1,S5,S6,S2,S21
			Multiplexed additive	V,C

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions	
		AT ECU	AL4 automatic gearbox	V,C,D,T,S1,S2,S12	
			colltrolled manual	V,C,D,T,S1,S12,S7,S13,S28	
		ABS	ABS MK70.1	V,C,D,T,S1,S17	
			ESP MK60-O	V,C,D,T,S1,S17,S16	
		Air bag	Airbag ECU	V,C,D,S1,S14	
		Driving assistance/Comfort	Parking assistance	V,C,D,T,S1	
			Air conditioning	V,C,D,T,S1	
			Under inflation	V,C,D	
			Power steering	V,C,D,S1	
		Inform the driver/Audio/Communication	Muti-function display	V,C,D,T,S1	
			Radio	V,C,D,T,S1	
			CD player	V,C,T,S30	
			Instrument panel	V,C,D,T,S1	
			Hands Free Kit	V,C,D,T,S1	
			Steering wheel	V,C,D,T	
			Telamatics	V,C,D,T,S1	
			Battery charge status	V,C,D,S1	
			Warning light showing seat belt not	V	
			Vehicle	Alarm	V,C,D,T,S1
			BSM	V,C,D,T	
			BSR	V,C,D,T	
			TNB	V,T	
		Visibility/Lighting/Signalling	Rain/Brightness sensor	V,C	
			Driving school module	V,C,T	
			Static AFS	V,C,D,T,S1	
			Folding roof	V,C,D,T	
			High frequency receiver	V,C,D	
			Services module	V,C,D,T,S1	
		Petrol engine	Built-in systems interface(BSI)		V,C,B1,D,S7,S29
				KFW J34P	V,C,D,T,S1,S2
HFX J34P	V,C,D,T,S1,S2				
HFV V34.3	V,C,D				
KFT V34.3	V,C,D				
TU5JP4 ME745	V,C,D,T,S1,S2,S3				
NFU Or N6A ME749	V,C,D,T,S1,S2,S9				
N6A ME749 BIO FLEX	V,C,D,T,S1,S2,S9				

		KFW ME749	V,C,D,T,S1,S2,S9
		KFW ME749 BIO FLEX	V,C,D,T,S1,S2,S9
		WJY DCN2	V,C,D
		RHY EDC15C2	V,C,D,T,S1,S5

## PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
207 VAN	2007->	Diesel engine	8HZ BOSCH EDC16C3	V,C,D,S4
			9HY BOSCH EDC16C3	V,C,D,S4
			8HR EDC17C10_BR2	V,C,D
		AT	AL4 automatic gearbox	V,C,D,T,S1,S2,S12
		A/C	Air conditioning	V,C,D,T,S1
			Display/Telematics/AM	V,C,D,T,S1
		Inform the driver/Audio/Communication	Display/Telematics/RT3	V,C,D,T,S1
			Steering wheel	V,C,D,T
			Radio	V,C,D,T,S1
			CD player	V,C,D,T,S1
			Instrument panel	V,C,D,T,S1,
			Switch module at the	V,C,D
			Stolen vehicle location	V,C,D
			Alarm	V,C,D,T,S1
		Active and passive safety	ABS MK70	V,C,D,T,S1,S17
			ESP MK60	V,C,D,T,S1,S17,S16
			Air bags	V,C,D,S1,S14
			Rain/brightness sensor	V,C
			Windscreenwiper(left-	V,C,D
			Services Module	V,C,D,T,S1
	Built-in systems interface(BSI)	V,C,B1,D,S7,S29		
Petrol engine	NFU Or N6A ME749	V,C,D,T,S1,S2,S9		
	N6A ME749 BIO FLEX	V,C,D,T,S1,S2,S9		
	KFW ME749	V,C,D,T,S1,S2,S9		
	KFW ME749 BIO FLEX	V,C,D,T,S1,S2,S9		
	KFW J34P	V,C,D,T,S1,S2		
	HFX J34P	V,C,D,T,S1,S2		
	N6B Or N6A Or NFU	V,C,D,T,S1,S2,S3		
	HFV V34.3	V,C,D		
	KFT V34.3	V,C,D		
Diesel engine	WJY DCN2	V,C,D		
	RHY EDC15C2	V,C,D,T,S1,S5		
	8HZ BOSCH EDC16C3	V,C,D,S4		
	9HY BOSCH EDC16C3	V,C,D,S4		
	8HR EDC17C10_BR2	V,C,D		
AT	AL4 AT8 automatic gearbox	V,C,D		
Driving	Heating/ventilation	V,C,D,T,S1		



207i	2010->	Inform the	Display/Telematics	V,C,D,T
			Steering wheel	V,C,D,T
			Radio	V,C,D,T,S1
			CD changer	V,C,D,T,S1

**PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
		driver/Audio/Communication	Instrument panel	V,C,D,T,S1
			Stolen vehicle location control unit	V,C,D
		Vehicle	Alarm	V,C,D,T,S1
		Active and passive safety	ABS MK70	V,C,D,T,S1
			ESP MK60	V,C,D,T,S1,S21
			Air bags	V,C
		Visibility/Lighting/Si	Rain/brightness sensor	V,C
			Windscreen	V,C,D,T
Multi-function display	V,C,D,T,S1			
Services module	V,C,D,T,S1			
HOGGAR	2010->	Built-in systems interface(BSI)		V,C,B1,D,S7,S29
		Petrol engine	NFU Or N6A ME749	V,C,D,T,S1,S2,S9
			N6A ME749 BIO FLEX	V,C,D,T,S1,S2,S9
			KFW ME749	V,C,D,T,S1,S2,S9
			KFW ME749 BIO FLEX	V,C,D,T,S1,S2,S9
			KFW J34P	V,C,D,T,S1,S2
			HFX J34P	V,C,D,T,S1,S2
			TU5JP4 ME745	V,C,D,T,S1,S2,S3
			HFV V34.3	V,C,D
			KFT V34.3	V,C,D
		WJY DCN2	V,C,D	
		Diesel engine	RHY EDC15C2	V,C,D,T,S1,S5
			8HZ BOSCH EDC16C3	V,C,D,S4
			9HY BOSCH EDC16C3	V,C,D,S4
			8HR EDC17C10_BR2	V,C,D
		AT	AL4 AT8 automatic gearbox	V,C,D
		Driving	Heating/ventilation	V,C,D,T,S1
		Inform the driver/Audio/Com	Display/Telematics	V,C,D,T
			Steering wheel	V,C,D,T
			Radio	V,C,D,T,S1
CD changer	V,C,D,T,S1			
Instrument panel	V,C,D,T,S1			

	munication	Stolen vehicle location control unit	V,C,D
Vehicle		Alarm	V,C,D,T,S1
		ABS MK70	V,C,D,T,S1
Active and passive		ESP MK60	V,C,D,T,S1,S21

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
		safety	Air bags	V,C
		Visibility/Lighting/Si	Rain/brightness sensor	V,C
			Windscreen	V,C,D,T
		Multi-function display	AMF	V,C,D,T,S1
			RT3	V,C,D,T,S1
			Services module	V,C,D,T,S1
		Built-in systems interface(BSI)		V,C,B1,D,S7,S29
		Petrol engine	5FS MEV17.4	V,C,D,T,S1,S2
			5FV MED17.4	V,C,D,T,S1,S2
			5FW MEV17.4	V,C,D,T,S1,S2
			5FX MED17.4	V,C,D,T,S1,S2
			MEC17_4_2 EP6C	V,C,D
			5FV MED 17.4.2 Euro5	V,C,D,T,S1,S2
		Diesel engine	9HZ EDC16C3	V,C,D,T,S1,S5,S6,S7
			9HL HDI SID807	V,C,D,T,S1,S5,S6,S2,S21
			9HR HDI SID807	V,C,D,T,S1,S5,S6,S2,S21
			RHE DCM3.5	V,C,D,T,S1,S5,S6,S7,S2,S21
			RHH DCM3.5	V,C,D,T,S1,S5,S6,S7,S2,S21
			DCM3.5_HY	V,C,D,T,S1,S2,S22
			DCM3.5_BR2	V,C,D
		AT ECU	CFC300P gearbox	V,C,D,T,S3,S12
			AM6 Euro5 automatic	V,C,D,T,S1,S12,S21
			AT6 Euro5 automatic gearbox	V,C,D,T,S1,S12
		Vehicle protection/Manage	Alarm	V,C,D,T,S1
			Driver's door control panel	V,C,D,T
			Audio amplifier	V,C,D,T,S1
			Multifunction display	V,C,D,T,S1
			Steering wheel switching module	V,C,D,T

3008	2009->	Inform the driver/Audio/Communication	Radio	V,C,D,T,S1
			Telematics	V,C,D,T,S1
			Services module	V,C,D,T,S1
			Instrument panel	V,C,D,T,S1
			Control panel dot	V,C,D,T,S1
			Battery charge status	V,C,D,S1
			CD player	V,C,T,S1,S30

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions		
			Not Fastened warning	V,T		
			Electric secondary	V,C,D		
		Driving assistance/Comfort	Air conditioning	V,C,D,T,S1		
			Parking assistance	V,C,D,T,S1		
			Power steering GEP	V,C,D,T		
			Anti-slip mode selector	V,C,D,T		
			Under inflation	V,C,D		
			Active and passive safety	ESP81	V,C,D,T,S1,S24,S25	
		Air bag		V,C,D,S1,S14		
		BSM		V,C,D,T		
		BSR		V,C,D,T		
		GEP		V,C,D,T		
		POMPE_MUX_MGI		V,C,D,T		
		POMPE_MUX_TI		V,C,D,T		
		FSE		V,C,D,T		
		TNB		V,T		
		Visibility/Lighting/Signalling		Rain sensor	V,C	
			Headlamp height	V,C,D,T,S1,S18		
			Windscreen wiper	V,C,D,T,S1		
			Electric power steering	V,C,D		
			Hands Free Kit	V,C,D,T,S1		
			High frequency receiver	V,C,D		
			High Head Vision	V,C,D,T,S1		
			Network isolation unit	V,D		
			Assistance in complying	V,C,D,T,S1		
		306	1993-1997	Petrol engine	HDY BOSCH MA3.1	V,C
					KFX MM1AP	V,C,D
HDZ BOSCH MA3.1	V,C					
NFZ BOSCH MP5.2	V,C,D					
RFS MM1AP	V,C,D,T,S2					
ABS	Anti lock brakes			V,C,D		

			BOSCH	
		Air bag	Air bag and seat belt	V,C,S3
		Petrol engine	KFX BOSCH MP7.3	V,C,D,T,S2
			NFZ BOSCH MP7.2	V,C,D,T
			KFX MM1AP	V,C,D
			KFX SAGEM SL96	V,C,D,T,S2
			LFY BOSCH MP7.3	V,C,D,T,S2
			LFY SAGEM SL96	V,C,D,T,S2
			NFT BOSCH M7.4.4	V,C,D,T,S1,S2
			KFW SAGEM S2000	V,C,D,T,S3,S2
			K6D SAGEM S2000	V,C,D,T,S3,S2

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
306REMO DELAJE	1997-2002		NFV BOSCH M7.4.4	V,C,D,T,S1,S2
			RFS MM1AP	V,C,D,T,S2
			RFV BOSCH MP5.2	V,C,D
			NFZ BOSCH MP5.2	V,C,D
			R6E BOSCH MP5.2	V,C,D
		Diesel engine	WJY LUCAS DCN2	V,C,D,T,S1
			WJZ LUCAS DCN2	V,C,D
			RHY BOSCH EDC15C2	V,C,D
		ABS	ABS BOSCH 5.3	V,C,D,T
		A/T	AL4 Gearbox	V,C,D,T,S3,S2,S12,S30
		Air bag	Air bag and seat belt	V,C,S3
		Left Air bag	Left side airbag	V,C,S3
		Right Air bag	Right side airbag	V,C,S3
		BSI		V,C,D,T,S3,B2
		Petrol engine	NFU BOSCH ME744	V,C,D,T,S1,S2
			KFW SAGEM S2000	V,C,D,T,S3,S2
			K6D SAGEM S2000	V,C,D,T,S3,S2
			N6A BOSCH ME7.4.4	V,C,D,T,S1,S2
			N6A BOSCH ME7.4.5	V,C,D,T,S1,S2,S3
			NFU BOSCH ME7.4.5	V,C,D,T,S1,S2,S3
			RFN	V,C,D,T,S2
			RFN	V,C,D,T
			KFU MM6LP	V,C,D,T,S1,S2
			RFK MM6LP	V,C,D,T,S1,S2
			RFN MM6LP	V,C,D,T,S1,S2
				RHZ BOSCH EDC15C2
		RHS BOSCH EDC15C2		V,C,D,T,S1,S30
		9HY BOSCH EDC16C3		V,C,D,S4
		RHY SIEMENS SID 801		V,C,D,T,S1
		RHY BOSCH EDC15C2		V,C,D
		9HZ BOSCH EDC16C3		V,C,D,T,S4,S30

307 VAN	2001-2005	Diesel engine	9HT BOSCH EDC16C3	V,C,D,T,S4,S30
			8HZ BOSCH EDC16C3	V,C,D,T,S1,S4
			9HX BOSCH EDC16C3	V,C,D,T,S4,S30
			9HY BOSCH EDC16C3 EUR04	V,C,D,T,S4,S30
			RHR SIEMENS SID 803	V,C,D,T,S1,S5
			RHL SIEMENS SID 803	V,C,D,T,S1,S5
		ABS	TEVES MK60 ABS	V,C,D
			ABS BOSCH 8	V,C,D,T,S1,S17
			ESP BOSCH 5.7	V,C,D,T,S1,S17,S16

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions		
			ABS BOSCH 5.3	V,C,D,T		
			ESP BOSCH 8	V,C,D,T,S1,S17,S16		
		A/T	BVA AL4	V,C,D,T,S3,S12		
			ZF 4HP20 AT	V,C,D		
		Air bag	SAC CENTRAL	V,C,D		
			Air bags(SAC CENT	V,C,S1		
		Driver information	Display/Telematics/AM	V,C,D,T,S1		
			Display/Telematics/RT3	V,C,D,T,S1		
			parking assistance	V,C,D,T		
			Radio	V,C,D,T,S1		
			CD player	V,C,D,T,S1		
			Switch unit under	V,C,D		
			Instrument panel	V,C,D,T,S1		
		Visibility/Lighting	Driving school	V,D,T		
		switch control	Driver's door module	V,C,D		
			Passenger door module	V,C,D,T		
			Diesel fuel additive	V,C,D,T,S3		
			Electric pump	V,C,D		
			Alarm	V,C,D,T,S1		
		A/C	Air conditioning	V,C,D,T,S1		
				Built-in systems interface(BSI)		V,C,D,B2,B1,S7,S29
				Petrol engine	N6A BOSCH ME745	V,C,D,T,S1,S2
					NFU BOSCH ME745	V,C,D,T,S1,S2
ME745 EC5	V,C,D,T,S1,S2,S21					
RFN MM6LP	V,C,D,T,S1,S2					
N6B BOSCH ME745	V,C,D,T,S1,S2					
KFU MM6LP	V,C,D,T,S1,S2					
RFK MM6LP	V,C,D,T,S1,S2					
RFJ MM6LPB	V,C,D,T,S1,S2,S3					

		KFU MM6LPC	V,C,D,T,S1,S2
		NFU Or N6A Or N6B	V,C,D,T,S1,S2,S9
		NFU Or N6A ME749 F	V,C,D,T,S1,S2,S9
		MM6KP Bio flex	V,C,D,T,S1,S2,S3,S9,S21
		MM6KP Non Bio Flex	V,C,D,T,S1,S2,S3,S9,S21
	Diesel engine	RHY BOSCH EDC15C2	V,C,D,T,S1,S5
		RHZ BOSCH EDC15C2	V,C,D,T,S1,S5
		9HV BOSCH EDC16C3	V,C,D,T,S1,S5,S6,S7
		9HX BOSCH EDC16C3	V,C,D,S1,S4
		9HY BOSCH EDC16C3	V,C,D,S1,S4
		9HY BOSCH EDC16C3	V,C,D,T,S1,S4
		9HZ BOSCH EDC16C3	V,C,S1,S5,S6,S7

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
307 CAN	2005->		9HT BOSCH EDC16C3	V,C,D,S1,S4
			RHR SIEMENS SID 803	V,C,D,T,S1,S5
			RHL SIEMENS SID 803	V,C,D,T,S1,S5
			RHL DCM3.4	V,C,D,T,S1,S5,S6,S7,S21,S2
			RHR DCM3.4	V,C,D,T,S1,S5,S6,S7
			Diesel additive function	V,C,D,T,S1
		AT ECU	AM6L4 automatic	V,C,D,T,S1,S12,S21
			AL4 automatic gearbox	V,C,D,T,S1,S2,S12
		Active and passive safety	ABS8 BOSCH	V,C,D,T,S1,S17,s21
			ABS 8.1	V,C,D,T,S1,S17
			ESP 8.1	V,C,D,T,S1,S17,S24
			ESP BOSCH 8	V,C,D,T,S1,S17,S16
			Airbag ECU	V,C,D,S1,S14
		Driving assistance/Comfort	Parking assistance	V,C,D,T,S1
			Air conditioning	V,C,D,T,S1
			Power steering	V,C,D,T
			Under inflation detection	V,C,D
		Inform the driver/Audio/Communication	Muti-function display	V,C,D,T,S1
			Radio	V,C,D,T,S1
			CD player	V,C,T,S30
			Hands Free Kit	V,C,D,T,S1
			Instrument panel	V,C,D,T,S1
			Steering wheel switching module	V,C,D,T
			Telamatics	V,C,D,T,S1
			Alarm	V,C,D,T,S1
			Driver's door module	V,C,D,T,S1

	Vehicle protection/Management of accesses	Passenger door module	V,C,D,T,S1
		Retractable roof	V,C,T
		Sun roof	V,C
	Visibility/Lighting/Signalling	Rain/Brightness sensor	V,C
		Right headlamp beam	V,C,D,T,S1,S18
		Left headlamp beam	V,C,D,T,S1,S18
		Driving school module	V,C,T
		Steering wheel	V,C,D,T
		Engine relay unit	V,C,D
		Trailer relay unit	V,C,D
	High frequency receiver	V,C,D	
	Service module	V,C,D,T,S1	

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
		Built-in systems interface(BSI)		V,C,D,B1,S7,S29
		Petrol engine	5FT MED17.4	V,C,D,T,S1,S2
			5FW MEV17.4	V,C,D,T,S1,S2
			5FX MED17.4	V,C,D,T,S1,S2
			5FV MED17.4	V,C,D,T,S1,S2
			5FS MEV17.4	V,C,D,T,S1,S2
			8FR MEV17.4	V,C,D,T,S1,S2
			5FY MED17.4	V,C,D,T,S1,S2
			8FS MEV17.4	V,C,D,T,S1,S2
			N6A ME745	V,C,D,T,S1,S2
			N6B ME745	V,C,D,T,S1,S2
			NFU ME745	V,C,D,T,S1,S2
			ME745 EC5	V,C,D,T,S1,S2,S21
			ME749 EC5	V,C,D,T,S1,S2,S21,S23
			NFU ME749 Bio Flex	V,C,D,T,S1,S2,S9
			MM6KP Bio flex	V,C,D,T,S1,S2,S9,S21
			MM6KP Non Bio Flex	V,C,D,T,S1,S2,S9,S21
			RFJ MM6LPB	V,C,D,T,S1,S2,S3
			5FU MEVD17.4.2	V,C,D,T,S1,S2
			EP6C 5FS MEV17.4.2	V,C,D,T,S1,S2
			EP3C 8FP MEV17.4.2	V,C,D,T,S1,S2
			EP3C 8FR MEV17.4.2	V,C,D,T,S1,S2
			9HV EDC16C3	V,C,D,T,S1,S5,S6,S7
			9HX EDC16C3	V,C,D,S1,S4
		9HY EDC16C3	V,C,D,S1,S4	
		9HZ EDC16C3	V,C,D,S1,S5,S6,S7	
		9HL HDI SID807	V,C,D,T,S1,S5,S6,S2,S21	
		9HR HDI SID807	V,C,D,T,S1,S5,S6,S2,S21	

			9HR HDI SID807 BR2	V,C,D,T,S1,S5,S6,S2
			9HL HDI SID807 BR2	V,C,D,T,S1,S5,S6,S2
			9HG HDI SID807 BR2	V,C,D,T,S1,S5,S6,S2
			9HP EDC17C10	V,C,D,T,S1,S5,S6,S2
			8HR EDC17C10	V,C,D,T,S1,S5,S6,S2
		Diesel engine	RHE DCM3.5	V,C,D,T,S1,S5,S6,S7,S2,S21
			RHH DCM3.5	V,C,D,T,S1,S5,S6,S7,S2,S21
			RHL DCM3.4	V,C,D,T,S1,S5,S6,S21,S22,S26
			RHR DCM3.4	V,C,D,T,S1,S5,S6,S7,S21,S22,S26

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
308	2007->		RHF DCM3.4	V,C,D,T,S1,S5,S6,S7,S21,S22,S26
			9HP EDC17C10_BR2	V,C,D,T,S1,S5,S6,S2,S21
			9HJ EDC17C10_BR2	V,C,D,T,S1,S5,S6,S2,S21
		A/T	CFC300P gearbox	V,C,D,T,S3,S12
			AM6C gearbox	V,C,D,T,S1,S12,S21
			AL4 gearbox	V,C,D,T,S1,S2,S12
			AM6 Euro5 automatic	V,C,D,T,S1,S12,S21
			AT6 Euro5 automatic	V,C,D,T,S1,S12
			Multiplexed additive	V,C
		Vehicle protection / Management of accesses	Alarm	V,C,D,T,S1
			Alarm lin	V,C,D,T,S1
			Control unit windscreen	V,C,T,S1
			Driver's door module	V,C,D,T
		Active and passive safety	ABS 8.1	V,C,D,T,S1,S17
			ESP 8.1	V,C,D,T,S1,S17,S24
			Air-bag	V,C,D,S1,S14
		Driving assistance/comfort	Lane departure warning	V,C,D,T,S1,S7
			Air conditioning	V,C,D,T,S1
			Electropump assembly	V,C
			Drivers seat memory	V,C,D,T,S1
			Parking assistance	V,C,D,T,S1
			Under inflation	V,C,D
			Passenger's seat	V,C,D,T,S1
			Multifunction screen	V,C,D,T,S1
			Radio	V,C,D,T,S1
			Instrument panel	V,C,D,T,S1
	Hands Free Kit	V,C,D,T,S1		



	Inform the driver/Audio/Communication	Not Fastened warning	V,T
		Telematics	V,C,D,T,S1
		Steering wheel	V,C,D,T
		CD player	V,C,T,S1,S30
		Audio amplifier	V,C,D,T,S1
		Battery charge status	V,C,D,S1
		Services Module	V,C,D,T,S1
		BSM	V,C,D,T
		BSR	V,C,D,T
	Visibility/Lighting/Signalling	Rain sensor	V,C
Discharge bulb with		V,C,D,T,S1,S18	
Driving school module		V,C,T	
Power steering GEP		V,C,D,T	

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
			Power steering electric	V,C,D
			Folding roof	V,C,D,T
			High frequency receiver	V,C,D
			Moving panel deflector	V,C,D,T,S2
			Sun roof	V,C,D
		Built-in systems interface(BSI)		V,C,D,B1,S7,S29
		Diesel engine	RHE DCM3.5	V,C,D,T,S1,S5,S6,S7,S2,S21
			RHH DCM3.5	V,C,D,T,S1,S5,S6,S7,S2,S21
			DCM3.4	V,C,D,T,S1,S7,S21,S22,S26
			HDI_SID807	V,C,D,T,S1,S5,S2,S21
			EDC17C10_BR2	V,C,D,T,S1,S2,S21,S22
			HDI_SID807_BR2	V,C,D,T,S1,S5,S2
			DCM3.5_BR2	V,C,D
		Petrol engine	5FS MEV17.4	V,C,D,T,S1,S2
			8FR MEV17.4	V,C,D,T,S1,S2
			5FT MED17.4	V,C,D,T,S1,S2
			5FW MEV17.4	V,C,D,T,S1,S2
			5FX MED17.4	V,C,D,T,S1,S2
			5FY MED17.4	V,C,D,T,S1,S2
			8FS MEV17.4	V,C,D,T,S1,S2
			5FV MED17.4	V,C,D,T,S1,S2
			5FU MEVD17.4.2	V,C,D,T,S1,S2
			EP3C 8FP MEV17.4.2	V,C,D,T,S1,S2
			EP3CM 8FP MEV17.4.2	V,C,D,T,S1,S2

		EP3C 8FR MEV17.4.2	V,C,D,T,S1,S2
		ME745 EC5	V,C,D,T,S1,S2,S21
		ME749 EC5	V,C,D,T,S1,S2,S21,S23
		EP6C 5FS MEV17.4.2	V,C,D,T,S1,S2
	Gearbox	AM6 Euro5 automatic gearbox	V,C,D,T,S1,S12,S21
		CFC300P gearbox	V,C,D,T,S3,S12
		AL4 gearbox	V,C,D,T,S1,S2,S12
		Multiplexed additive	V,C,D
		AT6 Euro5 automatic gearbox	V,C,D
	Driving assistance/Comfort	Heating/ventilation	V,C,D,T,S1
		Electropump assembly	V,C,D
		Parking assistance	V,C,D,T,S1
		Pedestrian impact	V,C,D

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
RCZ	2010->		Under inflation	V,C,D
			Moving panel deflector	V,C,D,T,S2
			Drivers seat memory unit	V,C,D,T,S1
		Vehicle protection	Alarm	V,C,D,T,S1
			Driver's door control pad	V,C,D,T
		Active and passive safety	Air-bag	V,C,D
			ABS8.1	V,C,D,T,S1,S24
			ESP8.1	V,C,D,T,S1,S24
		Inform the driver/Audio/Communication	Battery charge status unit	V,C,D,S1
			CD player	V,C,T,S1,S30
			Radio	V,C,D,T,S1
			Portable unit	V,C,D
			Instrument panel	V,C,D,T,S1
			Multifunction	V,C,D,T,S1
			Multifunction	V,C,D,T,S1
			Not Fastened warning	V,T
			Control panel dot	V,C,D,T,S1
Steering wheel	V,C,D,T			

			telematics/Radio navigation NG4	V,C,D,T
			Radio	V,C,D,T,S1
			Audio amplifier	V,C,D,T,S1
			BSM	V,C,D,T
			BSR	V,C,D,T
		Visibility/Lighting/Signalling	Discharge bulbs vertical	V,C,D,T,S1,S18
			Windscreen wiper	V,C,D,T,S1
			Rain / brightness sensor	V,C
			Power steering GEP	V,C,D,T
			Folding roof	V,C,D,T
			Hands Free Kit	V,C,D,T,S1
			High frequency receiver	V,C,D
			Lane departure warning	V,C,D,T,S1,S7
			Passenger's seat	V,C,D,T,S1
	Sun roof	V,C,D		
		N6A ME7.4.4	V,C,D,T,S1,S2	
		N6B ME7.4.4	V,C,D,T,S1,S2	
		NFU ME7.4.4	V,C,D,T,S1,S2	

**PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
405	1987-1996	Petrol engine	LFY BOSCH MP7.3	V,C,D,T,S1,S2
			L6A SAGEM SL96	V,C,D
			1600RD SL96	V,C,D
			LFZ SAGEM S2000	V,C,D,T,S2
			NFU J35	V,C,D,T,S1
406	1995-1999	Petrol engine	KFX SAGEM SL96	V,C,D,T,S2
			LFY BOSCH MP7.3	V,C,D,T,S2
			LFY BOSCH MP5.2	V,C,D
			LFX MM1AP	V,C,D,T,S2
			LFY SAGEM SL96	V,C,D,T,S2
			R6E BOSCH MP5.2	V,C,D
			RFV BOSCH MP5.2	V,C,D
			RGX BOSCH MP3.2	V,C,D
			XFZ BOSCH MP7.0	V,C,D
		Diesel engine	RHZ BOSCH EDC15C2	V,C,D,T,S1,S5,S30
		Active safety	ABS BOSCH 5.3	V,C,D,T
			Electronically managed	V,C,D
		A/T	AL4 autoadaptive	V,C,D
		Air bag	Air bag and seat belt	V,C,S3
Left Air bag	Left side airbag	V,C,S3		
Right Air bag	Right side airbag	V,C,S3		

406 COUPE	1995-1999	Petrol engine	RFV BOSCH MP5.2	V,C,D
			XFZ BOSCH MP7.0	V,C,D
		Air bag	Air bag and seat belt	V,C,S3
		Left Air bag	Left side airbag	V,C,S3
		Right Air bag	Right side airbag	V,C,S3
		A/T	AL4 autoadaptive	V,C,D
		ABS	BOSCH ABS5	V,C,D
BOSCH ABS5.3	V,C,D			
		Built-in systems interface(BSI)		V,C,D,B2,B1
		Petrol engine	XFX BOSCH ME 746	V,C,D,T,S1,S2
			LFY BOSCH MP5.2	V,C,D
			LFX MM1AP	V,C,D,T,S2
			LFY SAGEM SL96	V,C,D,T,S2
			LFY BOSCH MP7.3	V,C,D,T,S2
			3FZ MM4MP2	V,C,D,T
			RFN MM48P	V,C,D,T,S1,S2
			R6F MM48P	V,C,D,T,S2
			RFR MM48P	V,C,D,T,S2
			6FZ SAGEM S2000	V,C,D,T,S1,S2
			RLZ SIEMENS IRIUS81	V,C,D,T,S2
			RFV BOSCH MP5.2	V,C,D

--	--	--	--	--

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
406R	1999-2001		XFZ BOSCH MP7.0	V,C,D
			R6E BOSCH MP5.2	V,C,D
		Diesel engine	RHY BOSCH EDC15C2	V,C,D,S5
			4HX BOSCH EDC15C2	V,C,D
			RHY SIEMENS SID 801	V,C,D,T,S1
			RHS BOSCH EDC15C2	V,C,D,T,S1,S30
			RHZ BOSCH EDC15C2	V,C,D,T,S1,S5,S30
			Diesel fuel additive	V,C,D,T,S1
		ABS	ESP BOSCH 5.3	V,C,D
			ABS BOSCH 5.3	V,C,D,T
			Alarm	V,C,D,T,S1
			Rain/brightness sensor	V,C
		A/C	Air conditioning	V,C,D,T
		Driver information	Multi-function display	V,C,D,T,S1
			Radio	V,C,D,T,S1
			CD player	V,C,D,T
			On-board navigation	V,C,D
			Switch unit under	V,C,D
			Instrument panel	V,C,D,T,S1
		A/T	AL4 autoadaptive	V,C,D
	Air bags(SAC-CENT-	V,C,D,S1,S14		

		Air bag and seat belt	V,C,S3
		Air bag	Left side airbag Right side airbag
		Built-in systems interface(BSI)	V,C,D,B2,B1
406R	Petrol engine	XFX BOSCH ME 746	V,C,D,T,S1,S2
		LFY BOSCH MP5.2	V,C,D
		LFX MM1AP	V,C,D,T,S2
		LFY SAGEM SL96	V,C,D,T,S2
		LFY BOSCH MP7.3	V,C,D,T,S2
		3FZ MM4MP2	V,C,D,T
		RFN MM48P	V,C,D,T,S1,S2
		R6F MM48P	V,C,D,T,S2
		RFR MM48P	V,C,D,T,S2
		6FZ SAGEM S2000	V,C,D,T,S1,S2
		RLZ SIEMENS IRIUS81	V,C,D,T,S2
		RFV BOSCH MP5.2	V,C,D
		XFZ BOSCH MP7.0	V,C,D
		R6E BOSCH MP5.2	V,C,D
		Diesel engine	RHY BOSCH EDC15C2
	4HX BOSCH EDC15C2		V,C,D
	RHY SIEMENS SID 801		V,C,D,T,S1

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
COUPE	2001-2003		RHS BOSCH EDC15C2	V,C,D,T,S1,S5,S30
			RHZ BOSCH EDC15C2	V,C,D,T,S1,S5,S30
			Diesel fuel additive	V,C,D,T,S1
		ABS	ESP BOSCH 5.3	V,C,D
			ABS BOSCH 5.3	V,C,D,T
			Alarm	V,C,D,T,S1
			Rain/brightness sensor	V,C
		A/C	Air conditioning	V,C,D,T
		Driver information	Multi-function display	V,C,D,T,S1
			Radio	V,C,D,T,S1
			CD player	V,C,D,T
			On-board navigation	V,C,D
			Switch unit under	V,C,D
			Instrument panel	V,C,D,T
		A/T	AL4 autoadaptive	V,C,D
		Air bag	Air bags(SAC-CENT-	V,C,D,S1,S14
			Air bag and seat belt	V,C,S3
			Left side airbag	V,C,S3
			Right side airbag	V,C,S3
		Built-in systems interface(BSI)	V,C,D,B1,S7,S29	

		Diesel engine	RHR SIEMENS SID 803	V,C,D,T,S5
			RHL SIEMENS SID 803	V,C,D,T,S5
			RHL DCM3.4	V,C,D,T,S1,S5,S6,S7,S21,S2
			RHR DCM3.4	V,C,D,T,S1,S5,S6,S7,S21,S2
			RHF DCM3.4	V,C,D,T,S1,S5,S6,S7,S21,S2
			RHH DCM3.5	V,C,D,T,S1,S5,S6,S7,S2,S21
			UHZ SIEMENS SID 201	V,C,D,T,S1,S5,S6,S7
			4HP BOSCH EDC16CP39	V,C,D,T,S1,S5,S6,S7,S3
			4HR BOSCH EDC16CP39	V,C,D,T,S1,S5,S6,S7,S3
			4HS BOSCH EDC16CP39	V,C,D,T,S1,S5,S6,S7,S3
			4HT BOSCH EDC16CP39	V,C,D,T,S1,S5,S6,S7,S3
			9HT BOSCH EDC16C3	V,C,D,T,S4,S30
			9HY BOSCH EDC16C3	V,C,S4
			9HY BOSCH EDC16C3	V,C,D,T,S4,S30
			9HZ BOSCH EDC16C3	V,C,D,T,S4,S30
		EDC17CP11	V,C,D,T,S4,S30,S1,S7,S22	
		Petrol engine	XVF ME747	V,C,D,T,S1,S2,S30
			3FZ MM6LP	V,C,D,T,S1
			RFJ MM6LPB	V,C,D,T,S1,S2,S3
			3FY MM6LPB	V,C,D,T,S1,S2,S3
6FY MM6LPB	V,C,D,T,S1,S2,S3			
6FZ S2000PM2	V,C,D,T,S1,S2			

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
407	2004-2010		RFN MM6LP	V,C,D
			MM6KP Bio flex	V,C,D,T,S1,S2,S9,S21
			MM6KP Non Bio Flex	V,C,D,T,S1,S2,S9,S21
		ABS	Diesel fuel additive control unit	V,C,D,T,S1
			ESP8.1	V,C,D,T,S1,S17,S24
		A/T	ESP EBC 440(KWP)	V,C,D
			AL4 automatic gearbox	V,C,D,T,S1,S12,S3,S12
			4HP20 automatic	V,C,D,T,S1,S2
			AM6 automatic gearbox	V,C,D,T,S1,S12,S21
		Air bag	AM6 Euro5 automatic gearbox	V,C,D,T,S1,S12,S21
			Airbag ECU	V,C,D,S1,S14
		Inform the driver Audio/Communication	Muti-function display	V,C,D,T,S1
			Radio	V,C,D,T,S1
			CD player	V,C,T,S30
			Instrument panel	V,C,D,T,S1
			Telematics	V,C,D,T,S1

	Hands Free Kit	V,C,D,T,S1
Vehicle protection Management of accesses	Alarm	V,C,D,T,S1
	Driver's door module	V,C,D,T,S1
	Passenger door module	V,C,D,T,S1
	Passenger seat	V,C,D,T,S1
Visibility Lighting/Signalling	Control unit windscreen	V,C,D,T,S1
	Rain/Brightness sensor	V,C
	Steering wheel	V,C,D,T
Driving assistance/Comfort	Parking assistance	V,C,D,T,S1
	Air conditioning	V,C,D,T,S7
	Additional heating	V,C,D,T
	Power steering	V,C,D,T
	Piloted suspension	V,C,D,T,S3
	Battery charge status unit	V,C,D,S1
	Stop and Star battery	V,C,D,S1
	Under inflation	V,C,D
	Boot wiring	V,C,D,T
	Directional headlamps	V,C,D,T,S1
	Driver's seat	V,C,D,T,S1
	Trailer relay unit	V,C,D
	Engine relay unit	V,C,D
	High frequency receiver	V,C,D

### **PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
			Left headlamp beam	V,C,D,T,S1
			Right headlamp beam	V,C,D,T
			Sun roof	V,C,D
		Built-in systems interface(BSI)		V,C,D,B1,S7,S29
		Petrol engine	NFU ME745	V,C,D,T,S1,S2
			NFU ME749 Bio Flex	V,C,D,T,S1,S2,S9
			MM6KP Bio flex	V,C,D,T,S1,S2,S9,S21
			MM6KP Non Bio Flex	V,C,D,T,S1,S2,S9,S21
			RFJ MM6LPB	V,C,D,T,S1,S2,S3
			5FT MED17.4	V,C,D,T,S1,S2
			5FX MED17.4	V,C,D,T,S1,S2
			5FY MED17.4	V,C,D,T,S1,S2
			5FW MEV17.4	V,C,D,T,S1,S2
			8FS MEV17.4	V,C,D,T,S1,S2
			EP3C 8FP MEV17.4.2	V,C,D,T,S1,S2
			EP3CM 8FP MEV17.4.2	V,C,D,T,S1,S2
			EP3C 8FR MEV17.4.2	V,C,D,T,S1,S2

		EP6C 5FS MEV17.4.2	V,C,D,T,S1,S2
		ME745_EC5	V,C,D,T,S1,S2,S21
		ME749_EC5	V,C,D,T,S1,S2,S21,S23
		MED17_4_2	V,C,D
	Diesel engine	9HR HDI SID807 BR2	V,C,D,T,S1,S5,S6,S2
		9HL HDI SID807 BR2	V,C,D,T,S1,S5,S6,S2
		9HG HDI SID807 BR2	V,C,D,T,S1,S5,S6,S2
		HDI_SID807	V,C,D,T,S1,S5,S6,S2,S21
		DCM3.4	V,C,D,T,S1,S7,S21,S22,S26
		DCM3.5	V,C,D,T,S1,S2,S21,S22
		EDC17C10_BR2 DCM3.5_BR2	V,C,D,T,S1,S2,S21,S22
		V,C,D	
	Gearbox ECU	BVA_AM6_AT6_EURO5	V,C,D,T,S1,S12,S21
		BVA_AT8	V,C,D,T,S1,S2,S12
		BVA_AM6	V,C,D,T,S1,S12,S21
		CFC300P	V,C,D,T,S3,S12
		Multiplexed additive adding pump	V,C,D
	ABS	ESP8.1	V,C,D,T,S1,S24

### **PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
408	2010->		ABS8.1	V,C,D,T,S1,S24
		Air bag	Airbag ECU	V,C,D
		Driving assistance/Comfort	Parking assistance	V,C,D,T,S1
			Air conditioning	V,C,D,T,S1
			Under inflation	V,C,D
			Driver's seat	V,C,D,T,S1
			Lane departure warning system	V,C,D,T,S1,S7
		Inform the driver Audio/Communication	Muti-function display	V,C,D,T,S1
			Radio	V,C,D,T,S1
			CD player	V,C,T,S1,S30
			Instrument panel	V,C,D,T,S1
			Not Fastened warning light(TNB)	V,T
			Telematics	V,C,D,T
			Steering wheel switching module	V,C,D,T



			Audio amplifier	V,C,D,T,S1
			Battery charge status unit	V,C,D,S1
		Vehicle protection Management of accesses	Alarm	V,C,D,T,S1
			Alarm lin	V,C,D,T,S1
			Driver's door module	V,C,D,T
			Passenger door module	V,C,D,T
			Passenger seat	V,C,D,T,S1
			Windscreen wiper	V,C,T,S1
		Visibility Lighting/Signalling	Rain/Brightness sensor	V,C
			Discharge bulb with	V,C,D,T,S1,S18
			Driving school module	V,C,T
			BSM	V,C,D,T
			BSR	V,C,D,T
			Electric power steering	V,C,D,T
			Folding roof	V,C,D,T
			Hands Free Kit	V,C,D,T,S1
			High frequency receiver	V,C,D
			Moving panel deflector	V,C,D,T,S2
			Services Module	V,C,D,T,S1
			Sun roof	V,C,D
			Built-in systems interface(BSI)	V,C,S7,S29
			MM6KP Bio flex	V,C,D,T,S1,S2,S9,S21

**PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
		Petrol engine	MM6KP Non Bio Flex	V,C,D,T,S1,S2,S9,S21
			MED17.4.2	V,C,D,T,S1,S2
			MEV17.4.2	V,C,D,T,S1,S2
		Diesel engine	HDI SID807 BR2	V,C,D,T,S1,S2,S5
			DCM34	V,C,D,T,S1,S3,S21,S22
			DCM3.5_HY	V,C,D,T,S1,S2,S22
			DCM3.5 BR2	V,C,D,T,S1,S2
			DCM6.2	V,C,D,T,S1,S24,S27
			EDC17CP42	V,C,D,T,S1
		AT	BVA AM6 AT6 EURO05	V,C,D,T,S1,S12,S21
			BVA AM6 AT6 UDS	V,C,D,S7,S24
			CFC300P	V,C,D,T,S3,S12
		ABS	ABS 8.1	V,C,D,T,S1,S24
			ESP 8.1	V,C,D,T,S1,S24,S25
			SRS	V,C,D,T,S1
			COMBINE	V,C,D,T

		AIRCONDITION	V,C,D,T	
		Power steering electric pump unit	GEP	V,C,D,T
		Under-inflation detection (DSG)	DSG	V,C,D
		Active damper electronic unit	BEBA	V,C,D,T,S1
		Battery charge status unit	BECB_GEN2	V,C,D,S1
		Electric secondary brake	FSE	V,C,D
		Discharge bulbs	LADCT	V,C,D,T,S1,S18
		Additional heating	CHAUFF_ADD	V,C,D,T
		Engine relay unit	BSM_2010	V,C,D
		Trailer relay unit	BSG_2010_RQ	V,C,D
		Airbag	RBG_UDS	V,C,D
		Parking assistance	AAS_UDS	V,C,D,T,S1
		Anti-theft alarm	ALARME	V,C,D,T,S1
		Instrument panel	COMBINE_UDS	V,C,D,T,S1
		Multifunction	EMF_A_UDS	V,C,T,S1
			EMF_C_UDS	V,C,D,T,S1
		Data communication	RNEG2010	V,C,D
508	2011->			

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
		Independent telematic unit	BTA	V,C,D,T,S1
		Multiplexed control	FMUX	V,C,D,T
		Matrix screen	MATT_C_2010	V,C,T,S1
			MATT_M_2010	V,C,T,S1
		RD5 radio	RD5	V,C,D,T,S1
		Hands-free control	BML	V,C,D,S1,S7
		Telematic navigator	CRT_UDS	V,D,T
		Radio amplifier	AMPLI_AUDIO	V,C,D,T,S1

		Switch module under the steering wheel (top of	COM2008P	V,C,D,T
		Seat belts not fastened LED unit	TNB_2010	V,T
		Supply protection and management	BPGA2010	V,C,D
		Steering wheel with integral controls	VCI	V,C,D,T
		Rain and brightness	PLUIE_LUMINOSITE_UD	V,C,D,S21
		Air conditioning	CLIM_REGULEE_UDS	V,C,D,T,S30
		Rear air	CLIM_AR	V,D
		Motorised Boot	COFFRE_MOTORISE	V,C,D,T,S1
		Driver's seat memorizing unit	BDMC	V,C,D,T,S1
		Driver's door control pad	PDPC	V,C,D,T
		Central voltage	DMTC	V,C,D
		Electronic key	LCE	V,C,D
		High Head Vision	VTH_UDS	V,C,D,T,S1
		Main beams assistant ECU	RETRO_INT	V,C,D,T,S1
		Windscreen wiper (left-hand side)	MOTEV_UDS	V,C,D,T
		Windscreen wiper	MOTED_UDS	V,C,D,T
		Electric steering	AVE	V,C,D,T

### **PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
		Built-in systems interface(BSI)		V,C,D
		Diesel engine	EDC16CP39	V,C,D,T,S30
			4HK EDC16CP39	V,C,D,S5
			4HN EDC16CP39	V,C,D,S5
		Petrol engine	MIVEC	V,C,D,T,S30
			AFZ 4B11 MIVEC EURO4	V,C,D
			SFY 4B12 MIVEC EURO5	V,C,D
		A/T	SFZ 4B12 MIVEC EURO4	V,C,D
			CVT gearbox	V,C,D
			DCT controlled gearbox	V,C,D

4007	2008->	Engine/Automatic Gearbox/Transmissi	4x4 transmission	V,C,D
			LEVIER GETRAG	V,C,D
		Inform the driver/Audio/Communication	Radio	V,C,D,T
			Navigation	V,C
			Instrument panel	V,C,D,T,S1
			Hands Free Kit	V,C,D,T
		Vehicle protection/Management of accesses	Coded immobiliser	V,C,D
			Driver's door control	V,C,D,T
			Passenger's door	V,C,D
			Rear left door control	V,C,D
			Rear right door control	V,C,D
		Active and passive safety	Sun roof	V,C,D
			Air bag	V,C,D
			ABS or ESP ECU	V,C,D
		Visibility Lighting/Signalling	Flywheel angle sensor	V,C
			Static AFS	V,C,D
		Driving assistance/Comfort	Rain and brightness	
Air conditioning	V,C,D,T			
Parking assistance	V,C,D			
	Rear final drive piloted	V,C,D,T		
	BSI	V,C,D,T,S2		
Petrol engine	3FZ MM4MP2	V,C,D,T		
	RFN	V,C,D,T,S2		
	RFN	V,C,D,T		
	R6F MM4.8P	V,C,D,T,S2		
	XFX BOSCH ME7.4.6	V,C,D,T,S1,S2		
Diesel engine	RHS BOSCH EDC15C2	V,C,D,T,S1,S5,S30		
	4HX BOSCH EDC15C2	V,C,D		
	RHZ BOSCH EDC15C2	V,C,D,T,S1,S5,S30		
Active safety	ESP BOSCH 5.3	V,C,D		
	ABS BOSCH 5.3	V,C,D,T		
	Electronically managed	V,D,T,S1		

### **PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
607 VAN	1999-2004	A/T	BVA ZF	V,C,D
			4HP20 gearbox	V,C,D,T,S1,S2
		Air bag	Air bag	V,C
		Driver information	Multi-function display	V,C,D,T
			Parking assistance	V,C,D,T
			Instrument panel	V,C,S1
			CD player	V,C,D,T
		switch control	Radio	V,C,D,T,S1
			Driver's door control	V,C,D,T
			Passenger's door	V,C,D

		Visibility/Lighting	Headlamp height	V,C,D,T
			storing of the driving	V,C,D
			Diesel fuel additive	V,C,D,T,S3
		A/C	Air conditioning	V,C,D,T,S1
607 R	2004-2010	Built-in systems interface(BSI)		V,C,D,B1
		Petrol engine	3FZ MM6LP	V,C,D,T,S1,S2
			3FY MM6LPB	V,C,D,T,S1,S3
			XFV ME747	V,C,D,T,S1,S2
		Diesel engine	UHZ SIEMENS SID 201	V,C,D,T,S1,S5,S6,S7
			4HP BOSCH EDC16CP39	V,C,D,T,S1,S5,S6,S7,S3
			4HR BOSCH EDC16CP39	V,C,D,T,S1,S5,S6,S7,S3
			4HS BOSCH EDC16CP39	V,C,D,T,S1,S5,S6,S7,S3
			4HT BOSCH EDC16CP39	V,C,D,T,S1,S5,S6,S7,S3
			RHL SIEMENS SID 803	V,C,D,T,S1,S5
			RHR SIEMENS SID 803	V,C,D,T,S1,S5
			4HX BOSCH EDC15C2	V,C,D,T,S1,S5
			RHS BOSCH EDC15C2	V,C,D,T,S1,S5
			HDI SID803A	V,C,D
		AT ECU	AM6 automatic gearbox	V,C,D,T,S1,S12,S21
			4HP20 automatic	V,C,D,T,S1,S2
			Diesel fuel additive control unit	V,C,D,T,S1
		ABS	ESP BOSCH 8	V,C,D,T,S1,S17,S16
		Air bag	Airbag ECU	V,C,D,S1,S14
		Driving assistance/Comfort	Parking assistance	V,C,D,T,S1
Drivers seat memory unit	V,C,D,T,S1			
Air conditioning	V,C,D,T			
Under inflation detection	V,C,D			
Piloted suspension	V,C,D,T,S3			

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
			Power steering	V,C,D,T
		Inform the driver/Audio/Communication	Multi-function display	V,C,D,T,S1
			Radio	V,C,D,T,S1
			CD player	V,C,T,S30
			Instrument panel	V,C,D,T,S1
			Steering wheel	V,C,D,T
			Hands Free Kit	V,C,D,T,S1
			Telamatics	V,C,D,T,S1

		Vehicle protection/Management of accesses	Alarm	V,C,D,T,S1
			Driver's door module	V,C,D,T,S1
			Passenger door module	V,C,D,T,S1
		Visibility/Lighting/Si	Rain/Brightness sensor	V,C
		Engine relay unit		V,C,D
806	1994-2002	Petrol engine	R6F MM4.8P	V,C,D,T,S2
			RGX BOSCH MP3.2	V,C,D
			RFN MM4.8P	V,C,D,T,S1,S2
		Diesel engine	RHW BOSCH EDC15C2	V,C,D,T,S1,S5
			RHZ BOSCH EDC15C2	V,C,D,T,S1,S5,S30
		ABS	BOSCH ABS5.3	V,C,D
		AT	AL4 autoadaptive	V,C,D,T,S1,S2,S12
		Air bag	Air bag and seat belt	V,C,S3
Additional heating		V,C,D,T		
807 VAN	2002-2005	BSI		V,C,D
		Diesel engine	RHW BOSCH EDC15C2	V,C,D,T,S1,S5
			RHM BOSCH EDC15C2	V,C,D
			RHT BOSCH EDC15C2	V,C,D
			4HW BOSCH EDC15C2	V,C,D
		A/T	A4L automatic gearbox	V,C,D
		ABS	ABR BOSCH 5.7	V,C,D
			ESP BOSCH 5.7	V,C,D,T
		Driver information	Display/Telematics	V,C,D,T
			Warning light and	V,C,D
			Parking assistance	V,C,D
			CD player	V,C,D
			Instrument panel	V,C,D,T
			Switch unit under	V,C,D
		Visibility/Lighting	radio/telematic receive	V,C,D,T
Switch unit under	V,C,D			
Right headlamp beam	V,C,D			
		Left headlamp beam	V,C,D	

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
		switch control	Driver's door module	V,C,D,T
			Sliding side door	V,C,D
			Passenger's door	V,C,D
		A/C	WEBASTO additional	V,C,D
			Climate control	V,C,D
		Air bag	Air bag	V,C,D
			Diesel fuel additive	V,C,D
			Alarm	V,C,D,T

			Storing of the driving	V,C,D
		Petrol engine	3FZ MM4MP2	V,C,D
			3FZ MM6LP	V,C,D
			R6F MM4.8P	V,C,D,T,S2
			RFN	V,C,D,T,S1,S2
			RFN	V,C,D
			RFN MM6LP	V,C,D,S2
			XFW BOSCH ME746	V,C,D
		Built-in systems interface(BSI)		V,C,D,B2,B1
		Petrol engine	RFJ MM6LPB	V,C,D,T,S1,S3
		Diesel engine	4HW BOSCH EDC15C2	V,C,D,T,S1
			4HP EDC16CP39	V,C,D,T,S1,S4,S5,S6,S7,S3
			4HR EDC16CP39	V,C,D,T,S1,S4,S5,S6,S7,S3
			4HS EDC16CP39	V,C,D,T,S1,S4,S5,S6,S7,S3
			4HT EDC16CP39	V,C,D,T,S1,S4,S5,S6,S7,S3
			RHK SIEMENS SID 803	V,C,D,T,S1,S5
			RHL SIEMENS SID 803	V,C,D,T,S1,S5
			RHR SIEMENS SID 803	V,C,D,T,S1,S5
			RHM BOSCH EDC15C2	V,C,D,T,S1,S5
			RHT BOSCH EDC15C2	V,C,D,T,S1,S5
			RHH DCM3.5	V,C,D,T,S1,S5,S6,S7,S2,S21
			RHD DCM3.5	V,C,D,T,S1,S5,S6,S7,S2,S21
			RHW BOSCH EDC15C2	V,C,D,T,S1,S5
			Diesel fuel additive	
		ABS	ESP 8.1	V,C,D,T,S1,S24
			ESP BOSCH 8	V,C,D,T,S1,S17,S16
		Air bag	Airbag ECU	V,C,D,S1,S14
		A/T	BVA AL4	V,C,D,T,S1,S2,S12
			BVA AM6C	V,C,D,T,S1,S12,S21
			BVA AM6C AT6 EURO	V,C,D,T,S1,S12,S21
		Driving	Additional heating	V,C,D,T
			Air conditioning	V,C,D,T
			Driver's door module	V,C,D,T,S1
			Drivers seat memory	V,C,D,T,S1

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions	
807 CAN	2005->	assistance/Comfort	Parking assistance	V,C,D,T,S1	
			Power steering GEP	V,C,D,T	
			Under inflation detection	V,C,D	
				CD player	V,C,T,S30
				Hands Free Kit	V,C,D,T,S1
				Instrument panel	V,C,D,T,S1

		Inform the driver/Audio/Communication	Multi-function display	V,C,D,T,S1
			Radio	V,C,D,T,S1
			Telematic receiver control	V,D
			Telematics	V,C,D,T,S1
			Warning lights/odometer unit	V,C,D,T,S1
		Vehicle protection/Management of accesses	Alarm	V,C,D,T,S1
			Front sunroof	V,C,D,T,S1
			Middle sunroof	V,C,D,T,S1
			Rear sunroof	V,C,D,T,S1
			Driver's door module	V,C,D,T,S1
			Passenger door module	V,C,D,T,S1
		Visibility/Lighting/Signalling	Sliding side doors	V,C,D,T,S1
			Left headlamp beam	V,C,D,T
			Rain/brightness sensor	V,C
			Right headlamp beam	V,C,D,T,S1,S18
	Steering wheel	V,C,D,T		
	Engine relay unit	V,C,D		
	Trailer relay unit	V,C,D		
		Built-in systems interface(BSI)	V,C,B1,D,S7,S29	
		Petrol engine	5FS MEV17.4	V,C,D,T,S1,S2
			5FV MED17.4	V,C,D,T,S1,S2
			5FW MEV17.4	V,C,D,T,S1,S2
			5FX MED17.4	V,C,D,T,S1,S2
			MEC17_4_2 EP6C	V,C,D
			5FV MED 17.4.2 Euro5	V,C,D,T,S1,S2
		Diesel engine	9HL HDI SID807	V,C,D,T,S1,S5,S6,S2,S21
			9HR HDI SID807	V,C,D,T,S1,S5,S6,S2,S21
			HDI SID807 BR2	V,C,D,T,S1,S2,S5
			9HZ EDC16C3	V,C,D,T,S1,S5,S6,S7
			RHE DCM3.5	V,C,D,T,S1,S5,S6,S7,S2,S21
			DCM3.5 HY	V,C,D,T,S1,S2,S22

**PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
			DCM3.5 BR2	V,C,D
			RHH DCM3.5	V,C,D,T,S1,S5,S6,S7,S2,S21
			AM6 Euro5 automatic	V,C,D,T,S1,S12,S21
			CFC300P gearbox	V,C,D,T,S3,S12
			AT6 Euro5 automatic gearbox	V,C,D



5008	2010->	Gearbox	Multiplexed additive adding pump/Pompe	V,C,D
			Multiplexed additive	V,C,D
		Driving assistance/Comfort	Air conditioning ECU	V,C,D,T,S1
			Electric parking brake	V,C,D
			Electropump assembly	V,C,D
			High Head Vision	V,C,D,T,S1
			Lane departure warning	V,C,D
			Under inflation detection	V,C,D
			Parking aid	V,C,D,T,S1
			Assistance in complying	V,C,D,T,S1
		Visibility/Lighting/Si gnalling	Headlamp height corrector	V,C,D,T,S1,S18
			Windscreen wiper	V,C,D,T,S1
			Rain / brightness sensor	V,C
		Vehicle protection	Alarm	V,C,D,T,S1
			Driver's door control pad	V,C,D,T
		Active and passive safety	Airbag ECU	V,C,D,S1,S14
			ESP81	V,C,D,T,S1,S24,S25
			Active and passive	V,C,D
			Network isolation unit	V,C,D
			Anti-slip mode selector	V,C,D,T
		Inform the driver/Audio/Com munication	Battery charge status	V,C,D,S1
			Control panel dot	V,C,D,T,S1
			Multifunction	V,C,D,T,S1
			Multifunction	V,C,D,T,S1
			Not Fastened warning	V,T
			Services module	V,C,D,T,S1
			Steering wheel	V,C,D,T
			Independent telematic	V,C,D,T,S1
			Control panel	V,C,D,T,S1
			telematics/RNEG radio	V,C,D,T

**PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
			telematics/Radio	V,C,D,T
			Radio	V,C,D,T,S1
			CD player	V,C,T,S1,S30

			Audio amplifier	V,C,D,T,S1	
			Electric secondary	V,C,D	
			Engine relay unit	V,C,D	
			Hands-free kit	V,C,D,T,S1	
			High frequency receiver	V,C,D	
			Network isolation unit	V,C,D	
			Trailer relay unit	V,C,D	
BIPPER	2008->	Built-in systems interface(BSI)		V,C,D	
		Petrol engine	KFT V34.2	V,C,D	
			KFV V34P	V,C,D	
		Diesel engine	8HS EDC16C34	V,C,D	
			HDI 8DF2	V,C,D	
		AT	BVMP	V,C,D,S12,S21,S28	
			Controlled manual	V,C,D	
			Instrument panel	V,C,D,T	
		ABS or ESP ECU	ABS81	V,C,D,T	
			ESP81	V,C,D,S21	
	Air bag	V,C,D			
	Parking aid	V,C,D,S1			
		Built-in systems interface(BSI)		V,C,D,B2,B1	
		Petrol engine	HDY BOSCH MA3.1	V,C	
			HDZ BOSCH MA3.1	V,C	
			HFX BOSCH M7.4.4	V,C,D,T,S1,S2	
			KFX BOSCH MP7.3	V,C,D,T,S2	
			KFX MM1AP	V,C,D	
			KFX SGEAM SL96	V,C,D,T,S2	
			LFX MM1AP	V,C,D,T,S2	
			N6A BOSCH ME7.4.4	V,C,D,T,S1,S2	
			KFW SAGEM S2000	V,C,D,T,S3,S2	
			K6D SAGEM S2000	V,C,D,T,S3,S2	
			NFU BOSCH ME7.4.4	V,C,D,T,S1,S2	
			RFN MM6LP	V,C,D,S2	
			KFW SAGEM S2000PM1	V,C,D,T,S1,S2	
			N6A BOSCH ME7.4.5	V,C,D,T,S1,S2,S3	
			N6B BOSCH ME7.4.5	V,C,D,T,S1,S2,S3	
			NFU BOSCH ME7.4.5	V,C,D,T,S1,S2,S3	
			NFU Or N6A BOSCH	V,C,D,T,S1,S2,S9	
			N6A BOSCH ME749 BIO FLEX	V,C,D,T,S1,S2,S9	
			<b>PEUGEOT V10.12 Diagnostics List(Note:For reference only)</b>		
<b>Vehicle</b>	<b>Year</b>		<b>System</b>	<b>ECU Type</b>	<b>Functions</b>
			KFW BOSCH ME749	V,C,D,T,S1,S2,S9	

PARTNER	1997-2008		KFW BOSCH ME749 BIO	V,C,D,T,S1,S2,S9
			KFW SAGEM S2000PM2	V,C,D
			HFX MM48P	V,C,D,T,S1,S2
			KFW J34P	V,C,D,T,S1,S2
		Diesel engine	WJY LUCAS DCN2	V,C,D,T,S1
			RHY SIEMENS SID 801	V,C,D,T,S1
			RHY BOSCH EDC15C2	V,C,D,S5
			9HW BOSCH EDC16C3	V,C,D,T,S1,S4,S30
			9HX BOSCH EDC16C3	V,C,D,T,S1,S4,S30
			9HT BOSCH EDC16C3	V,C,D,T,S1,S4,S30
			WJZ LUCAS DCN2	V,C,D
			ABS	BOSCH ABS5.3
		BOSCH ABS5		V,C,D
		ABS BOSCH 8		V,C,D,T,S1,S17
		ESP BOSCH 5.7		V,C,D,T
		ESP BOSCH 8		V,C,D,T,S1,S17,S16
		ABS 8.1		V,C,D,T,S1,S17
		ESP 8.1		V,C,D,T,S1,S17
		Inform the driver/Audio/Communication	Telematics	V,C,D,T,S1
			Instrument panel	V,C,D,T,S1
			CD player	V,C,D,T
			Radio PHILIPS	V,C,D,T,S1
			Radio CLARION	V,C,D,T,S1
		A/C	WEBASTO additional	V,C,D
		Air bag	Air bag and seat belt	V,C,S3
			Air bags(SAC CENT	V,C,D,S1,S14
		Additional heating		V,C,D,T
		Radio	AutoRadio	V,C,D,T,S1
			RDE	V,C,D,T
			Services module	V,C,D,T
			Steering wheel	V,C,D,T
			Alarm	V,C,D
	Rain and brightness	V,C		
	Built-in systems interface(BSI)	V,C,D,B1,S7,S29		
Petrol engine	N6A ME7.4.5	V,C,D,T,S1,S2,S3		
	N6B ME7.4.5	V,C,D,T,S1,S2,S3		
	NFU ME7.4.5	V,C,D,T,S1,S2,S3		
	NFR ME745	V,C,D,T,S1,S2,S3		

**PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
---------	------	--------	----------	-----------

PARTNER B9	2008->		5FS MEV17.4	V,C,D,T,S1,S2	
			5FK MEV17.4	V,C,D,T,S1,S2	
		Diesel engine	9HT EDC16C3	V,C,D,T,S1,S2	
			9HX EDC16C3	V,C,D,T,S1,S4	
			9HZ EDC16C3	V,C,D,T,S1,S5,S6,S7	
			9HS BOSCH EDC16C3	V,C,D,T,S1,S5,S6,S7	
			9HV EDC16C3	V,C,D,T,S1,S5,S6,S7	
			9HW EDC16C3	V,C,D,T,S1,S4	
			EDC17C10 BR2	V,C,D,T,S1,S2,S21,S22	
			9HL HDI SID807	V,C,D,T,S1,S5,S6,S2,S21	
			HDI SID807 BR2	V,C,D,T,S1,S2,S5	
			9HJ EDC17C10 BR2 -	V,C,D,T,S1,S5,S6	
			9HK EDC17C10 BR2 -	V,C,D,T,S1,S5,S6	
			9HE EDC17C10 BR2 -	V,C,D,T,S1,S5,S6	
			Active and passive safety	ABS 8.1	V,C,D,T,S1,S17
				ESP 8.1	V,C,D,T,S1,S17,S24
		Air bags		V,C,D,S1,S14	
		Alarm		V,C,D,T,S1	
		Gearbox	CFC300P	V,C,D,T,S3,S12	
		Visibility/Lighting/Si	Rain sensor	V,C	
		Inform the driver/Audio/Communication	Multifunction display	V,C,D,T,S1	
			Steering wheel	V,C,D,T	
			Radio	V,C,D,T,S1	
			Hands Free Kit	V,C,D,T,S1	
			Instrument panel	V,C,D,T,S1	
			CD player	V,C,T,S1,S30	
			Battery charge status	V,C,D,S1	
			Telematics	V,C,D,T,S1	
		Driving assistance/Comfort	Parking assistance	V,C,D,T,S1	
			Air conditioning	V,C,D,T,S1,S7	
			Power steering	V,C,D,T	
			Under inflation	V,C,D	
			Anti-slip mode selector	V,C,D,T	
			Bodywork conversion	V,C,D,T	
	Engine relay unit	V,C,D			
	Trailer relay unit	V,C,D			
	High frequency receiver	V,C,D			
	Onboard change of the	V,C,D			
	Services module	V,C,D,T,S1			
Petrol engine	R6F MM4.8P	V,C,D,T,S2			
	RFN MM4.8P	V,C,D,T,S1,S2			

--	--	--	--	--

## PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
EXPERT	1995-2007	Diesel engine	WJY LUCAS DCN2	V,C,D,T,S1
			RHW BOSCH EDC15C2	V,C,D,T,S1,S5
			RHX BOSCH EDC15C2	V,C,D,T,S1,S5
			RHZ BOSCH EDC15C2	V,C,D,T,S1,S5,S30
		AT	AL4 autoadaptive	V,C,D,T,S1,S1,S12
		ABS	BOSCH ABS5.3	V,C,D
		Air bag	Air bag and seat belt	V,C,S3
	Additional heating		V,C,D,T	
EXPERT 2	1995-2007	Built-in systems interface(BSI)		V,C,D,B1
		Petrol engine	RFH MM6KP(EW10A)	V,C,D,T,S1,S2,S9,S21
		Diesel engine	9HU BOSCH EDC16C3-	V,C,D,T,S1,S4
			9HT BOSCH EDC16C3	V,C,D,T,S1,S4
			RHH DCM3.5	V,C,D,T,S1,S5,S6,S7
			RHG SIEMENS SID 803	V,C,D,T,S1,S5
			RHK SIEMENS SID 803	V,C,D,T,S1,S5
			RHL SIEMENS SID 803	V,C,D,T,S1,S5
			DCM3.5 BR2	V,C,D
			RHR SIEMENS SID 803	V,C,D,T,S1,S5
		Gearbox	BVA AM6 AT6 EURO5	V,C,D
		Active and passive safety	ABS8 BOSCH	V,C,D,T,S1,S17,S16
			ESP BOSCH8	V,C,D,T,S1,S17,S16
			ABS8.1	V,C,D,T,S1,S17
			ESP8.1	V,C,D,T,S1,S17,S24
			Airbag ECU	V,C,D,S1,S14
		Driving assistance/Comfort	Parking assistance	V,C,D,T,S1
			Air conditioning	V,C,D,T,S1,S7
			Power steering	V,C,D,T
			Pneumatic suspension	V,C,D,T,S1,S3,S15
			Additional heating	V,C,D,T
		Inform the driver/Audio/Communication	Multi-function display	V,C,D,T,S1
			Steering wheel	V,C,D,T
			Radio	V,C,D,T,S1
			Instrument panel	V,C,D,T,S1
			Hands Free Kit	V,C,D,T,S1
			CD player	V,C,T
Telematics	V,C,D,T,S1			
Vehicle protection	Alarm	V,C,D		
	Engine relay unit	V,C,D		
Visibility/Lighting/Si	Rain/brightness sensor	V,C		
	MM48p 2L essence	V,C,D		
	MM48p 2L dual	V,C,D		

## PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
BOXER	1981-2006		MM48p 2L Unleaded	V,C,D
		Diesel engine	2.0L HDI BOSCH	C,D,T
		Gearbox	4HP20 automatic	V,C,D
BOXER 3	2006-2011	Built-in systems interface(BSI)		V,C,D
		Engine_ECU	EDC17CP52	V,C,D
		Active and passive safety	ABS 8.0	V,C,D,T,S17
			ESP 8.0	V,C,D,T,S17,S16
			ASR 8.0	V,C,D,T,S17
			Airbag	V,C,D
			Additional heating	V,C,D,T
			Tachograph	V,C,D
	Power steering	V,C,D		
BOXER 3 minibus	2006->	Engine_ECU	EDC17CP52	V,C,D
		Active and passive safety	ABS 8.0	V,C,D,T,S17
			ESP 8.0	V,C,D,T,S17,S16
			ASR 8.0	V,C,D,T,S17
			Airbag	V,C,D
			Additional heating	V,C,D,T
	Power steering	V,C,D		
208	2012->	Built-in systems interface(BSI)		V,C,S7,S29
		Engine_ECU	EDC17C10_BR2	V,C,D
			MEV17_4_2	V,C,D,S1,S2
			HDI_SID807_BR2	V,C,D,T,S1,S2,S5
			V46	V,C,D
			ME749_EC5	V,C,D
			MED17_4_2	V,C,D,S1,S2
			EDC17C10_BR2	V,C,D,S1,S2,S21,S22
			MEVD17_4_2	V,C,D,T,S1,S2
		ABS or ESP ECU	ABSMK100	V,C,D,T,S1,S21
			EPSMK100	V,C,D,T,S1,S21
		Gearbox	CFC300P	V,C,D,T,S3,S12
			BVMP	V,C,D,T,S7,S12,S28
			BVA_AL4	V,C,D,T,S1,S2,,S12
			MAPS_UDS	V,C,D,S3,S12,S21
		Electric power steering		V,C,D,S1
		Trailer relay unit		V,C,D
		Airbag		V,C,D
		Parking aid		V,C,D,T,S1
		Air conditioning	TDC_RFTA_MUX	V,C,D,T,S1,S30
			TDC_CH_MUX	V,C,D,T,S30
TDC_RF_MUX	V,C,D,T,S30			

## PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
		Radio		V,C,D,T,S1
		Rain and brightness sensor		V,C,D,S21
		Independent telematic unit(BTA)	BTA	V,C,D,T,S1
			BLW	V,C,D
		Instrument panel		V,C,D,T,S1
		Audio amplifier		V,C,D,T,S1
		Matrix screen integral to the	MATT_C_2010	V,C,T,S1
			MATT_M_2010	V,C,T,S1
		Multiplexed control panel		V,C,D,T
		CD player		V,C,D,T,S1
		Steering wheel with integral controls		V,C,D,T
		Battery charge status unit		V,C,D,S1
		Telematic		V,C,D
		Siren		V,C,D,T,S1
		Anti-theft alarm		V,C,D,T,S1
		Multiplexed additive pump		V,C,D
		Switch module under the steering wheel		V,C,D,T
		Driving school mode		V,C,T
		Lighting relay unit		V,C,D,T
		301	2013->	Built-in systems interface(BSI)
Engine_ECU	EDC17C10_BR2			V,C,D,T,S1,S2,S21,S22
	ME745_EC5			V,C,D,T,S1,S2,S21
	V46_21			V,C,D
ABS or ESP ECU	ABS MK100			V,C,D,T,S1,S21
	ESP MK100			V,C,D,T,S1,S21
Gearbox	BVA_AL4			V,C,D,T,S1,S2,S12
	MAPS_UDS			V,C,D,S3,S12,S21
Airbag				V,C,D
	Multifunction screen			V,C,D,T,S1
	Switch module at the steering wheel			V,C,D,T
	Instrument panel			V,C,D,T,S1
	Parking assistance			V,C,D,T,S1
	Trailer relay unit			V,C,D
Radio	RDE			V,C,D,T,S1
	RD45			V,C,D,T,S1
	Electric power steering			V,C,D,S1
	Siren	V,C,D,T,S1		

## PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
			Multiplexed additive pump	V,C,D
2008	2013->	Built-in systems interface(BSI)		V,C,S7,S29
		Injection	ECD17C10_BR2	V,C,D
			MEV17_4_2	V,C,D,S1,S2
			HDI_SID807_BR2	V,C,D,T,S1,S2,S5
			V46	V,C,D
			ME749_EC5	V,C,D
			EDC17C10_BR2	V,C,D,T,S1,S2,S21,S22
			MED17_4_2	V,C,D,S1,S2
		ABS or ESP ECU	ESPMK100	V,C,D,T,S1,S21
			ABSMK100	V,C,D,T,S1,S21
		Gearbox	CFC300P	V,C,D,T,S3,S12
			BVMP	V,C,D,T,S7,S12,S28
			BVA_AL4	V,C,D,T,S1,S2,S12
			MAPS_UDS	V,C,D,S3,S12,S21
		Airbag		V,C,D
			Telematic	V,C,D
			Rain and brightness sensor	V,C,D,S21
			Siren	V,C,D,T,S1
			Anti-theft alarm	V,C,D,T,S1
			Audio amplifier	V,C,D,T,S1
			External CD player	V,C,D,T,S1
			Battery charge status unit	V,C,D,S1
			Instrument panel	V,C,D,T,S1
			Multiplexed control panel	V,C,D,T
			Trailer relay unit	V,C,D
			Switch module under the steering wheel(top of column)	V,C,D,T
			Radio	V,C,D,T,S1
			Electric power steering	V,C,D,T
			Steering wheel with integral controls(VCI)	V,C,D,T
			Air conditioning	V,C,D,T,S1,S30



			Parking aid	V,C,D,T,S1
<b>PEUGEOT V10.12 Diagnostics List(Note:For reference only)</b>				
Vehicle	Year	System	ECU Type	Functions
			Matrix screen integral to the instrument panel	V,C,T,S1
			Independent telematic unit(BTA)	V,C,D,T,S1
			Multiplexed additive adding pump	V,C,D
3008 HYdrid4	2009->	Built-in systems interface(BSI)		V,C,D,S7,S29
		Engine_ECU	DCM35_HY	V,C,D,T,S1,S2,S22
			HDI_SID807_BR2	V,C,D,T,S1,S2,S5
			MEV17_4_EURO5	V,C,D
		ABS or ESP ECU	ESP81	V,C,D,T,S1,S24,S25
		MCP piloted manual gearbox(hybrid)		V,C,D,S12,S21,S30
		Airbag		V,C,D
			Hybrid mode selector	V,C,D,T
			Traction battery ECU	V,C,D,T
			Matrix screen integral to the instrument panel	V,C,D,T,S1
			Parking aid	V,C,D,T,S1
			Hybrid control ECU 1	V,C,D,T
			Hybrid control ECU 2	V,C,D
		Telematic	RADIONAV_NG4	V,C,D
			RNEG2010	V,C,D
			RADIONAV_RNEG	V,C,D
			RADIONAV_RNEGC	V,C,D
			Power steering electric pump unit	V,C,D,T
			Rain sensor	V,C,D
			Instrument panel	V,C,D,T,S1
			Battery charge status unit	V,C,D,S1
			Multiplexed additive adding pump	V,C,D
	Switch module under	V,C,D,T		
	Electric secondary brake	V,C,D		

Radio	AutoRadio	V,C,D,T,S1
	RD43	V,C,D,S1
	RD45	V,C,D,T,S1

## PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
			Anti-theft alarm	V,C,D,T,S1
		Services module	BLVV	V,C,D,T,S1
			MD_SERV	V,C,D,T,S1
			BTA	V,C,D,T,S1
			Air conditioning ECU	V,C,D,T,S1
		Multifunction display	EMF_A	V,C,D,T,S1
			EMF_C	V,C,D,T,S1
			Engine relay unit	V,C,D
			High Head Vision	V,C,D,T,S1
			Trailer relay unit	V,C,D
			Hands Free Kit	V,C,D,T,S1
			Windscreen wiper	V,C,T,S1
			Audio amplifier	V,C,D,T,S1
			Door control pad	V,C,D,T
			CD player	V,C,T,S1,S30
		Built-in systems interface(BSI)		V,C,D,S7,S29
		Engine_ECU	MED17_4_2	V,C,D,T,S1,S2
			EDC16C3	V,C,D
			MEV17_4_EURO4	V,C,D
			MED17_4_EURO4	V,C,D
			MEV17_4_EURO5	V,C,D
			MED17_4_EURO5	V,C,D
			DCM35	V,C,D
			HDI_SID807	V,C,D
			HDI_SID807_BR2	V,C,D,T,S1,S2,S5
			MM6KP	V,C,D,T,S1,S2,S9,S21
			DCM3.5_HY	V,C,D,T,S1,S2,S22
			DCM3.5_BR2	V,C,D
			MEC17_4_2 EP6C	V,C,D
		ABS or ESP ECU	ESP81	V,C,D,T,S1,S24,S25
		Gearbox	BVA_AM6_AT6_EURO5	V,C,D,T,S1,S12,S21
			CFC300P	V,C,D,T,S3,S12
		Airbag		V,C,D

			Power steering electric pump unit	V,C,D,T	
			Engine relay unit	V,C,D	
<b>PEUGEOT V10.12 Diagnostics List(Note:For reference only)</b>					
Vehicle	Year	System	ECU Type	Functions	
3008_Chine	2009->		Switch module under the steering wheel(top of the column)	V,C,D,T	
		Telematic	RADIONAV_NG4	V,C,D	
			RADIONAV_RNEG	V,C,D	
			RADIONAV_RNEG_C	V,C,D	
			RNEG2010	V,C,D	
				Instrument panel	V,C,D,T,S1
				Windscreen wiper	V,C,T,S1
		Radio	RD43	V,C,D,S1	
			AutoRadio	V,C,D,T,S1	
			RD45	V,C,D,T,S1	
				Air conditioning ECU	V,C,D,T,S1
				Anti-theft alarm	V,C,D,T,S1
				High Head Vision	V,C,D,T,S1
				Door control pad	V,C,D,T
				Rain and brightness	V,C
				Matrix screen integral to the instrument panel	V,C,D,T,S1
		Multifunction display	EMF_A	V,C,D,T,S1	
			EMF_C	V,C,D,T,S1	
				Electric secondary brake	V,C,D
				Anti-slip mode selector	V,C,D,T
		Parking aid	V,C,D,T,S1		
Engine_ECU	MM6KP	V,C,D			
	DCM6.2	V,C,D,T,S1,S24,S27			
	DCM35_HY	V,C,D,T,S1,S2,S22			
Gearbox		V,C,D,S12,S21,S30			
ABS/traction control	ABS81	V,C,D,T,S1,S24			
	ESP81	V,C,D,T,S1,S24,S25			
Airbag		V,C,D			

			Power steering electric pump unit	V,C,D,T
			Hybrid control ECU1	V,C,D,T
			Hybrid control ECU2	V,C,D
			Traction battery ECU	V,C,D,T
<b>PEUGEOT V10.12 Diagnostics List(Note:For reference only)</b>				
Vehicle	Year	System	ECU Type	Functions
508 RXH	2011->		Hybrid mode selector	V,C,D,T
			Electric secondary brake	V,C,D
			Battery charge status unit	V,C,D,S1
			Discharge bulbs vertical and horizontal adjustment	V,C,D,T,S1,S18
			Additional heating	V,C,D,T
			Engine relay unit	V,C,D
			Trailer relay unit	V,C,D
			Instrument panel	V,C,D,T,S1
			Multifunction screen	V,C,D
			Independent telematic unit(BTA)	V,C,D
			Anti-theft alarm	V,C,D,T
			Electronic key reader	V,C,D
			Driver's seat memorizing unit	V,C,D,T,S1
			Parking assistance	V,C,D,T,S1
			Data communication ECU RT6	V,C,D
			Multiplexed control panel	V,C,D,T
			Matrix screen integral to the instrument panel	V,C,T
			RD5 radio	V,C,D,T
	Hands Free control Kit	V,C,D,T,S1,S7		
	Telematic navigator	V,D,T		
	Audio amplifier	V,C,D,T,S1		

		Seat belt not fastened LED unit(TNB)	V,C,D,T
		Air conditioning	V,C,D,T,S30
		Rear air conditioning	V,C,D
		Supply protection and management unit	V,C,D

**PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
			Windscreen wiper(right-hand side)	V,C,D,T
			Windscreen wiper(left-hand side)	V,C,D,T
			Steering wheel with integral controls(VCI)	V,C,D,T
			Main beams assistant ECU	V,C,D,T,S1
			High Head Vision	V,C,D,T,S1
			Door control pad	V,C,D,T
			Switch module under the steering wheel (top of column)	V,C,D,T
			Electric steering lock	V,C,D
		Engine_ECU	MM6KP	V,C,D
			DCM6.2	V,C,D,T,S1,S24,S27
			DCM35_HY	V,C,D,T,S1,S2,S22
		Gearbox		V,C,D,S12,S21,S30
		ABS/traction control	ABS81	V,C,D,T,S1,S24
			ESP81	V,C,D,T,S1,S24,S25
		Airbag		V,C,D
			Power steering electric pump unit	V,C,D,T
			Hybrid control ECU1	V,C,D,T
			Hybrid control ECU2	V,C,D
			Traction battery ECU	V,C,D,T
			Hybrid mode selector	V,C,D,T
			Electric secondary	V,C,D
			Battery charge status	V,C,D,S1

		Discharge bulbs vertical and horizontal adjustment	V,C,D,T,S1,S18
		Additional heating	V,C,D,T
		Engine relay unit	V,C,D
		Trailer relay unit	V,C,D
		Instrument panel	V,C,D,T,S1
		Multifunction screen	V,C,D
		Independent telematic unit(BTA)	V,C,D

**PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
508HYBrid 4	2011->		Anti-theft alarm	V,C,D,T
			Electronic key reader	V,C,D
			Driver's seat memorizing unit	V,C,D,T,S1
			Parking assistance	V,C,D,T,S1
			Data communication	V,C,D
			Multiplexed control	V,C,D,T
			Matrix screen integral to the instrument panel	V,C,T
			RD5 radio	V,C,D,T
			Hands Free control Kit	V,C,D,T,S1,S7
			Telematic navigator	V,C,D,T
			Audio amplifier	V,C,D,T,S1
			Seat belt not fastened LED unit(TNB)	V,T
			Air conditioning	V,C,D,T,S30
			Rear air conditioning	V,C,D
			Supply protection and	V,C,D
			Windscreen	V,C,D,T
			Windscreen wiper(left-	V,C,D,T
			Steering wheel with integral controls(VCI)	V,C,D,T
			Main beams assistant ECU	V,C,D,T,S1
			High Head Vision	V,C,D,T,S1
	Door control pad	V,C,D,T		

			Switch module under the steering wheel (top of column)	V,C,D,T
			Electric steering lock	V,C,D
		ESP(ABS)		V,C,D
		Airbag	SRS	V,C,D
			ORC	V,C,D
			Electric machine management ECU	V,C,D,T
			Traction battery ECU	V,C,D,T

--	--	--	--	--

**PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
iON	2012->		Electric vehicle management ECU	V,C,D,T
			Traction battery cell management ECU01	V,D
			Traction battery cell management ECU02	V,D
			Traction battery cell management ECU03	V,D
			Traction battery cell management ECU04	V,D
			Traction battery cell management ECU05	V,D
			Traction battery cell management ECU06	V,D
			Traction battery cell management ECU07	V,D
			Traction battery cell management ECU08	V,D
			Traction battery cell management ECU09	V,D
			Traction battery cell management ECU10	V,D
			Traction battery cell management ECU11	V,D
				Electric power steering ECU

		Steering wheel angle sensor	V,C,D
		Gateway wiring housing	V,C,D
		Independent telematic unit(BTA)	V,C,D,T,S1
		Instrument panel	V,C,D,T
		Radio post-equipment	V,C,D,T,S1
Air conditioning		COMP_HTR	V,C,D
		Onboard change of the traction battery	V,C,D
		Diret voltage(DC/DC) transformer	V,C,D

**PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
		Built-in systems interface(BSI)		V,C,D,S7,S29
		Injection	MEV17_4_2	V,C,D,T,S1,S2
			EDC16C3	V,C,D
			ME745	V,C,D,T,S1,S2,S3
			MM6LPC	V,C,D
			MED17_4 EURO4	V,C,D
			MEV17_4 EURO4	V,C,D
			J34P	V,C,D
			MEV17_4 EURO5	V,C,D
			HDI_SID807	V,C,D
			V341	V,C,D
			EDC16C3DV4	V,C,D,T,S1,S21,S26
			EDC17C10	V,C,D
			HDI_SID807_BR2	V,C,D,T,S1,S2,S5
			EDC17C10_BR2	V,C,D
		Gearbox	BVA_AL4	V,C,D,T,S1,S2,S12
			BVMP_MA	V,C,D,T,S7,S12,S28
		ABS/traction control	ABSMK70_1	V,C,D,T,S1
			ESPMK60_O	V,C,D,T,S1,S21
			Electric power steering	V,C,D,S1
			Diesel additive	V,C,D
			Under inflation detection	V,C,D



207+	2012->		Battery charge status unit	V,C,D,S1
			Directional headlamps	V,C,D,T,S1
			Engine relay unit Trailer	V,C,D
			relay unit	V,C,D
			Driver and passenger airbags	V,C,D
			Heating/ventilation	V,C,D,T
			Switch module under the steering wheel	V,C,D,T
			Instrument panel	V,C,D,T,S1
			Multifunction display	V,C,D,T,S1
			Parking aid	V,C,D,T,S1
			Radio or radiotelephone(radio part)	V,C,D,T,S1

**PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
			Telematic	V,C,D
			CD player	V,C,T,S30
			Hands Free Kit	V,C,D,T,S1
			Anti-theft alarm	V,C,D,T,S1
			Folding roof	V,C,D,T
			Driving school mode	V,C,T
			High frequency receiver	V,C,D
			Seat belts not fastened LED unit	V,T
			Services module	V,C,D,T,S1
			Rain sensor/Brightness	V,C
208 ai91	2012->	Gearbox		V,C,D
		ABS or ESP ECU		V,C,D
		Air bag		V,C,D
		Built-in systems interface(BSI)		V,C,D,S7,S29
			DCM35_BR2	V,C,D
			DCM3.4	V,C,D
			DCM35	V,C,D
			EDC16C3	V,C,D
			MED17_4_EURO4	V,C,D

		Injection	MEV17_4_EURO4	V,C,D
			MM6LPB	V,C,D,T,S1,S2,S3
			ME745	V,C,D,T,S1,S2,S3
			ME749 Flex Fuel	V,C,D
			ME749_EC5	V,C,D,T,S1,S2,S21,S23
			MM6KP	V,C,D
			MEV17_4_EURO5	V,C,D
			MED17_4_EURO5	V,C,D
			HDI_SID807	V,C,D
			EDC17C10	V,C,D
			ECD17C10_BR2	V,C,D
			MEV17_4_2	V,C,D,T,S1,S2
			HDI_SID807_BR2	V,C,D
			MEVD17_4_2	V,C,D,T,S1,S2
			MED17_4_2	V,C,D
			ME745_EC5	V,C,D,T,S1,S2,S21
ABS/traction control	ABS 81	V,C,D,T,S1,S24		

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
308 4 portes	2007->		81 ESP	V,C,D,T,S1,S24
		Gearbox	BVA_AM6_AT6_EURO5	V,C,D,T,S1,S12,S21
			BVA_AT8	V,C,D,T,S1,S2,S12
			BVA_AM6	V,C,D,T,S1,S12,S21
			CFC300P	V,C,D,T,S3,S12
		Driver and		V,C,D
		Multiplexed additive pump	Pompe mux MGI	V,C,D
			Pompe mux TI	V,C,D
			Under inflation	V,C,D
			Directional headlamps	V,C,D,T,S1,S18
		Battery charge status unit	BECB	V,C,D,S1
			BECB_GEN2	V,C,D,S1
			Lane departure warning system	V,C,D,T,S1,S7
			Engine relay unit	V,C,D
		Multifunction display	Multifunction display(EMF)	V,C,D,T,S1
			EMF_A	V,C,D,T,S1

		Windscreen wiper	V,C,T,S1
		Parking aid	V,C,D,T,S1
		Heating/ventilation	V,C,D,T,S1
		Switch module under the steering wheel	V,C,D,T
		Instrument panel	V,C,D,T,S1
		CD player	V,C,T,S1,S30
	Telematic	RADIONAV_RNEG	V,C,D
		RADIONAV_NG4	V,C,D
		BOITIER_TELEMATIQUE	V,C,D
		RADIONAV_RNEGC	V,C,D
		ADIONAV_RNEGC_ECO	V,C,D
		RNEG2010	V,C,D
		Audio amplifier	V,C,D,T,S1
	Hands Free Kit	KML	V,C,D,T,S1
		BOITIER_NOMADE	V,C,D,T,S1

### **PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
			Driver's seat memorizing unit	V,C,D,T,S1
			Anti-theft alarm	V,C,D,T,S1
			Passenger seat memorisation unit	V,C,D,T,S1
			Door control pad	V,C,D,T
			Sun roof	V,C,D
			Moving panel deflector	V,C,D,T,S2
			Folding roof	V,C,D,T
		Services module	BLVV	V,C,D,T,S1
			MD_SERV	V,C,D,T,S1
			BTA	V,C,D,T,S1
			Driving school mode	V,C,T
			Rain and brightness sensor	V,C
			Seat belts not fastened LED unit	V,T

			Matrix screen integral to the instrument panel	V,C,D,T,S1	
		Injection	EDC16C3	V,C,D	
			ECD17C10_BR2	V,C,D,T,S1,S2,S21,S22	
			HDI_SID803A	V,C,D	
			MM6KP	V,C,D,T,S1,S2,S21	
			DCM3.5	V,C,D,T,S1,S2,S21,S22	
			DCM35_BR2	V,C,D	
		Gearbox			V,C,D,T,S1,S12,S21
		ABS/traction control	ABS81		V,C,D,T,S1,S21
			ESP81		V,C,D,T,S1,S24
			ABS 8_BOSCH		V,C,D
			ESP 8_BOSCH		V,C,D,T,S1,S21
		Driver and passenger airbags			V,C,D
			Power steering electric		V,C,D,T
			Deflation detection(DSG)		V,C,D
			Pneumatic suspension		V,C,D,T,S1
	Additional heating		V,C,D,T		
	Trailer relay unit		V,C,D		

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
EXPERT 3	2007->		Bodywork conversion unit	V,C,D,T
			Instrument panel	V,C,D,T,S1
			Parking aid	V,C,D,T,S1
			Switch module under	V,C,D,T
		Multifunction display	EMF_A	V,C,D,T,S1
			EMF_C	V,C,D,T,S1
			Heating/ventilation	V,C,D,T,S1,S7
			CD player	V,C,T,S1,S30
		Hands Free Kit	KML	V,C,D,T,S1
			BOITIER_NOMADE	V,C,D,T
		Telematic	BOITIER_TELEMATIQUE	V,C,D
			RADIONAV_RNEG	V,C,D
			RNEG2010	V,C,D
	Anti-slip mode	V,C,D,T		

			selector	
			Rear air conditioning table	V,C,D,T
			Rain and brightness sensor	V,C
			High frequency receiver	V,C,D
			Battery charge status unit	V,C,D,S1
BOXER3_E uro5	2011->	Built-in systems interface(BSI)		V,C,D
		ABS/traction control	ABS90_F	V,C,D
			ESP90_F	V,C,D
		Injection	EDC17CP52_UDS	V,C,D,T,S1,S21,S22
			SID208	V,C,D,T,S1,S21
			Additional heating	V,C,D,T
			Power steering	V,C,D
			Air conditioning	V,C,D,T,S7
	Instrument panel	V,C,D,T		
	Parking aid	V,C,D,S1		
		Built-in systems interface(BSI)		V,C,D
		Gearbox ECU		V,C,D
		Driver and passenger airbags		V,C,D
			Rear final drive piloted clutch	V,C,D,T

**PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
4008	2012->		Coded anti-start/hands-free control unit	V,C,D
			Starting authorisation ECU	V,C,D,T
			Calculateur stop and start	V,C,D
			Steering wheel angle sensor	V,C
			Parking aid	V,C,D
			Instrument panel	V,C,D,T,S1
			Heating/ventilation	V,C,D,T
		Power steering	V,C,D	

			Radio or radiotelephone(radio part)	V,C,D,T
			Navigation	V,C
		ABS/traction control	ABS	V,C,D
			ESP	V,C,D
605	1899-1998	Petrol engine	RFV BOSCH MP5.2	V,C,D
			R6E BOSCH MP5.2	V,C,D
			RGX BOSCH MP3.2	V,C,D
			XFZ BOSCH MP7.0	V,C,D
PARTNER Electric(B9 e)	2012->		Traction battery cell electronics01	V,D
			Traction battery cell electronics02	V,D
			Traction battery cell electronics03	V,D
			Traction battery cell electronics04	V,D
			Traction battery cell electronics05	V,D
			Traction battery cell electronics06	V,D
			Traction battery cell electronics07	V,D
			Traction battery cell electronics08	V,D

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
			Traction battery cell electronics09	V,D
			Traction battery cell electronics10	V,D
			Instrument panel	V,C,D,T,S1
			Passenger compartment air heating	V,C,D,T
			Air conditioning compressor	V,C,D,T
			Rain sensor	V,C

			Electric machine management ECU	V,C,D,T
		Built-in Systems Interface	BSI2010	
		Engine ECU	DCM6.2	
			HDI_SID807_BR2	V,C,D,T
			MED17_4_2	V,C,D,S1,S2
			EDC17C10_BR2	
			V46	
			V46_21	
			VD46	
			EDC17C60	V,C,D
			MED17_4_4	V,C,D
			MEVD17_4_4	
		Anti-lock braking system (ABS) or electric stability program (ESP)	ESP 90	V,C,D,T
		Gearbox	BVA_AM6_AT6_UDS	V,C,D,T
		Air bag	RBG_UDS	V,C,D,S14
		Trailer relay unit	BSG_2010_RQ	V,C,D,T
		Engine relay unit	BSM_2010	V,C,D,T
		Display	EMF_A_UDS	V,C,T
			EMF_C_UDS	V,C,D,T
		Switch module under the steering	COM2008P	V,C,D,T
			HDC	V,C,D,T

**PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
		Headlamp height adjuster/directional headlamp	LADCT	V,C,D,T
		External CD player	CDE	V,C,D,T
		Supply protection and management	BPGA2010	V,C,D
		Anti-theft alarm	MUS	V,C,D,T,S1
		Door control pad	PDPC_UDS	V,C,D,T
		Electric power steering	DAE_BVH2	V,C,D
		Electric key reader	LCE	V,C,D
		Electric steering	AVE	V,C,D,T

308\_T9

Diesel additive function	PADDGO_INERGY	V,C,D
Telematics unit SMEG_PLUS	SMEG_PLUS	V,C,D,T
Vehicle distance assistance	ARTIV_UDS	V,C
Air conditioning	BCC	V,C,D,T
Controls on the steering wheel	VCI	V,C,D,T
Touch screen	EMF_DGT_UDS	V,C,D,T
Rain-sunlight	CDPL_UDS_HELLA	V,C,D
Parking aid	AAS_UDS	V,C,D
Seat driver position memory module	BDMC	V,C,D,T
Battery charge status unit	BECB_GEN2	V,C,D
audio amplifier	AMPLI_AUDIO	V,C,T
Hands free starting access electronic module	BML	V,C,D,T,S1
Independent telematic unit	BTA	V,C,D,T
Multiplexed control panel	FMUX	V,C,D,T
Siren	SIR	V,C,D,T,S1

### PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle	Year	System	ECU Type	Functions
		Radiotelephone transceiver control	CRT_UDS_KOSTAL	V,C,D,T
		Radio	RD45	V,C,D,T
		Instrument panel	COMBINE_UDS	V,C,D,T
		Matrix screen integral to the	MATT_C_2010	V,C,T,S1
			MATT_M_2010	V,C,T
		Seat belts not fastened LED unit	TNB_2010	V,T
		Additional heating	CHAUFF_ADD	V,C,D,T
		Voltage retaining device	DMTR	V,C



408_T93	Built-in Systems Interface	BSI2010	
	Engine ECU	V46_32	V,C,D
		VD46	
		MED17_4_4	
	Anti-lock braking system (ABS) or electric stability program (ESP)	ESP 90	V,C,D,T
	Gearbox	BVA_AM6_AT6_UDS	V,C,D,T
	Telematics unit(RTX) or radio	MRN	V,C,D,T
	Air bag	RBG_UDS	V,C,D,S14
	Radiotelephone transceiver control	CRT_UDS_KOSTAL	V,C,D,T
	Electric power steering	DAE_BVH2	V,C,D
	Instrument panel	COMBINE_UDS_2	V,C,D,T
	Rain-sunlight	CDPL_UDS_HELLA	V,C,D
	Multiplexed control panel	FMUX	V,C,D,T
	Seat driver position memory module	BDMC	V,C,D,T
	Engine relay unit	BSM_2010	V,C,D,T
Matrix screen integral to the	MATT_C_2010	V,C,T,S1	
	MATT_M_2010	V,C,T	

**PEUGEOT V10.12 Diagnostics List(Note:For reference only)**

Vehicle	Year	System	ECU Type	Functions
		Supply protection and management	BPGA2010	V,C,D
		Electric key reader	LCE	V,C,D
		Electric steering	AVE	V,C,D,T
		Voltage retaining device	DMTR	V,C
		Battery charge status unit	BECB_GEN2	V,C,D
		Radio	RD45	V,C,D,T
			COM2008P	V,C,D,T

	Switch module under the steering	HDC	V,C,D,T
	Headlamp height adjuster/directional headlamp	LADCT	V,C,D,T
	Parking aid	AAS_UDS	V,C,D
	Display	EMF_A_UDS	V,C,T
		EMF_C_UDS	V,C,D,T
	Hands free starting access electronic module	BML	V,C,D,T,S1
	Air conditioning	BCC	V,C,D,T
	Touch screen	EMF_DGT_UDS	V,C,D,T
	Independent telematic unit	BTA_CN	V,C,D,T
	Anti-theft alarm	ALARME	V,C,D,T
	Controls on the steering wheel	VCI	V,C,D,T

Notes:	
V	System Version Info
C	DTC
D	Data Display
T	Action Test
B1	Reset maintenance indicator
B2	Immobilizer Key Programming
S1	Configuration
S2	Initialization
S3	Programming/Matching

## PEUGEOT V10.12 Diagnostics List(Note:For reference only)

Vehicle  
Year  
System  
ECU Type  
Functions

S4

Injector program

S5

Diesel Particulate Filter Reset and

S6

Diesel additive maintenance

S7

Diesel learning

S8

Injector replacement

S9

Writing percentage of ethanol

S10

Temporary reactivation of the

S12

Oil wear counter

S13

Reset Transmission Adapts

S14

SRS locking/unlocking

S15

Learn Tire Pressure Sensors

S16

Steering wheel adjustment

S17

Automated Bleed

S18

Suspension Position Calibration

S19

Initialise ESP sensors

S20

Reset ECU

S21

Replacement parts

S22

Particulate emission filter repair

S23

Writing of the alcohol content

S24

Spare part

S25

fic after sales operations

S26

Pairing

S27

Service action

S28

Stalling

S29

Maintenance-BSI operating mode

S30

Specific operation