

SmartV10.09 Diagnostics List									
Model	System	Rok	Functions						
Fortwo (W450)	N3/10(MEG motor electronics control unit)-EU2	1998-2002	√	√	√	√	√	√	
	N3/10(MEG motor electronics control unit)-EU3	1998-2002	√	√	√	√	√	√	
	N3/10(MEG motor electronics control unit)-EU4	2003-2005	√	√	√	√	√	√	
	N10/10(SAM control unit)	1998-2005	√	√	√	√	√	√	
	N10/10(ZEE control unit)	1998-2005	√	√	√	√			
	N47-5(ESP control unit)	1998-2005	√	√	√	√	√		
	N47-7(ABS control module)	1998-2005	√	√	√	√			
	N2/7(Restrain systems control unit)	1998-2005	√	√	√	√			
	A1(Instrument cluster)	1998-2005	√	√	√	√	√	√	
	N68(Steering assist control module)	1998-2005	√	√	√	√			
Roadster (W452)	N3/10(MEG motor electronics control unit)-E	2003-2005	√	√	√	√	√	√	
	N10/10(SAM control unit)	1998-2005	√	√	√	√	√	√	
	N10/10(ZEE control unit)	1998-2005	√	√	√	√			
	N47-5(ESP control unit)	1998-2005	√	√	√	√	√	√	
	N47-7(ABS control module)	1998-2005	√	√	√	√			
	N2/7(Restrain systems control unit)	1998-2005	√	√	√	√			
	A1(Instrument cluster)	1998-2005	√	√	√	√	√	√	
	N68(Steering assist control module)	1998-2005	√	√	√	√			
	N3/10(MEG motor electronics control unit)		√	√	√	√	√	√	
Forfour (W454)	N10/10(Left SAM control unit)		√	√	√	√	√	√	
	A1(Instrument cluster)		√	√	√	√	√	√	
	N47-5/7(ESP/ABS control module)		√	√	√	√	√	√	
	N2/7(restraint systems control module)		√	√	√		√		
	N68(Steering assist control module)		√	√	√	√	√		
	N22(AAC pushbutton control module)		√	√	√	√	√	√	
	N93(Central gateway control module)		√	√	√	√			
	N93/1(Audio gateway control module)		√	√	√	√			
	N3/9(EDG control unit)		√	√	√	√	√	√	
	N39(CDI control unit)		√	√	√	√	√	√	

SmartV10.09D Electronics List							
Model	System	Rok	Functions				
			√	√	√	√	√
Fortwo (W451)	N15/6(Sprintshift control module)		√	√	√	√	
	N10/10(SAM control unit)		√	√	√	√	√
	A1(Instrument cluster)		√	√	√	√	√
	N47-5(ESP control unit)		√	√	√	√	
	N2/7(Restrain systems control unit)		√	√	√	√	√
	N68(Steering assist control module)		√	√	√	√	
	N23(Heater/air conditioning operating unit)		√	√	√	√	√
	N15/5(Electronic selector lever module control unit)		√	√	√	√	√
	N88/1(Tire pressure monitoring system (TPM[RDK]))		√	√	√	√	√
	N110(Weight Sensing System (WSS) control unit)		√	√	√	√	
	A2/1(Radio 9)						√
	N3/10(ME-SFI [ME] control unit)		√	√	√	√	√
	N129(Starter generator squib)		√	√	√		
	Convertible top						√
	N82/2(Battery management system control unit)		√	√	√	√	√
	N127(Drivetrain control unit)		√	√	√	√	√
	N2/1(Crash sensor, hight-voltage battery)						
	N129/1(Power electronics control unit)		√	√	√	√	√
	N83(Onboard charge 3KW)		√	√	√	√	√
	N83/10(Onboard charge 22KW)		√	√	√	√	√
	N83n1(Powerline gateway contol unit)						
	H4/16(Electric vehicle sound generator)		√	√	√	√	√
	N112/2(Electric vehicle communication module control						